

This user manual includes detailed usage instructions for your camera. Please read this manual thoroughly.

User Manual st6500

0			

Basic troubleshooting

Quick reference

Contents

Basic functions

Extended functions

Shooting options

Playback/Editing

Settings

Appendixes

Index

Health and safety information

Always comply with the following precautions and usage tips to avoid dangerous situations and ensure peak performance of your camera.



Warning—situations that could cause injury to yourself or others

Do not disassemble or attempt to repair your camera.

This may result in electric shock or damage to the camera.

Do not use your camera near flammable or explosive gases and liquids.

This may cause a fire or explosion.

Do not insert flammable materials into the camera or store these materials near the camera.

This may cause a fire or electric shock.

Do not handle your camera with wet hands.

This may result in electric shock.

Prevent damage to subjects' eyesight.

Do not use the flash in close proximity (closer than 1 m/3 ft) to people or animals. If you use the flash too close to your subject's eyes, this can cause temporary or permanent eyesight damage.

Keep your camera away from small children and pets.

Keep your camera and all accessories out of the reach of small children and animals. Small parts may cause choking or serious injury if swallowed. Moving parts and accessories may present physical dangers as well.

Do not expose the camera to direct sunlight or high temperatures for an extended period of time.

Prolonged exposure to sunlight or extreme temperatures can cause permanent damage to your camera's internal components.

Avoid covering the camera or charger with blankets or clothes.

The camera may overheat, which may distort the camera or cause a fire.

If liquid or foreign objects enter your camera, immediately disconnect all power sources, such as the battery or charger, and then contact a Samsung service center.



Caution—situations that could cause damage to your camera or other equipment

Remove the batteries from your camera when storing it for an extended period of time.

Installed batteries may leak or corrode over time and cause serious damage to your camera.

Use only authentic, manufacturer-recommended, Lithium-ion replacement batteries. Do not damage or heat the battery.

Inauthentic, damaged, or heated batteries may cause a fire or personal injury.

Use only Samsung-approved batteries, chargers, cables and accessories.

- Using unauthorized batteries, chargers, cables or accessories can cause the batteries to explode, damage your camera, or cause injury.
- Samsung is not responsible for damage or injuries caused by unapproved batteries, chargers, cables or accessories.

Use the battery only for its intended purpose.

Misusing the battery may cause a fire or electric shock.

Do not touch the flash while it fires.

The flash is very hot when fired and may burn your skin.

When you use AC charger, turn off the camera before you disconnect the power to the AC charger.

Failing to do so may result in fire or electric shock.

Disconnect the charger from the wall socket when not in use.

Failing to do so may result in fire or electric shock.

Do not use a damaged power supply cord, plug, or loose outlet when you charge batteries.

This may cause a fire or electric shock.

Do not allow the AC charger to come in contact with the +/terminals on the battery.

This may cause a fire or electric shock.

Do not force the camera's parts or apply pressure to the camera.

This may cause your camera to malfunction.

Exercise caution when you connect cables or adapters and install batteries and memory cards.

If you force the connectors, improperly connect cables, or improperly install batteries and memory cards, you can damage ports, connectors, and accessories.

Keep cards with magnetic strips away from the camera case.

Information stored on the card may be damaged or erased.

Never use a damaged charger, battery, or memory card.

This may result in electric shock or camera malfunction or cause a fire.

Check that the camera is operating properly before use.

The manufacturer takes no responsibility for any loss of files or damage that may result from camera malfunction or improper use.

You must plug the end of the USB cable with the indicator light into your camera.

If the cable is reversed, it may damage your files. The manufacturer is not responsible for any loss of data.

Copyright information

- Microsoft Windows and the Windows logo are registered trademarks of the Microsoft Corporation.
- · Mac is a registered trademark of the Apple Corporation.
- HDMI, the HDMI logo and the term "High Definition Multimedia Interface" are trademarks or registered trademarks of HDMI Licensing LLC.
- microSD™ and microSDHC™ are registered trademarks of the SD Association.
- Trademarks and trade names used in this manual are the property of their respective owners.
 - Camera specifications or contents of this manual may be changed without prior notice due to upgrade of camera functions.
 - You are not allowed to reuse or distribute any part of this manual without prior permission.
 - For Open Source License information, refer to the 'OpenSourceInfo.pdf' in the provided CD-ROM.

Outline of the User Manual

Basic functions	12
Learn about your camera's layout, icons, and basic functions for shooting.	
Extended functions	32
Learn how to capture a photo, record a video, and record a voice memo by selecting a mode.	
Shooting options	50
Learn how to set the options in Shooting mode.	
Playback/Editing	79
Learn how to play back photos, videos, or voice memos and edit photos or videos. Also, learn how to connect your camera to your computer, photo printer, TV, or HDTV.	
Settings	107
Refer to options to configure your camera's settings.	
Appendixes	114

Icons used in this manual

Icon	Function
	Additional information
<u>^</u>	Safety warnings and precautions
[]	Camera buttons. For example, [Shutter] represents the shutter button.
()	Page number of related information
\rightarrow	The order of options or menus you must select to perform a step; for example: Touch ■ → Photo Size (represents Touch ■ , and then touch Photo Size).
*	Annotation

Abbreviations used in this manual

Abbreviation	Definition
ACB	Auto Contrast Balance
AEB	Auto Exposure Bracket
AF	Auto Focus
DIS	Digital Image Stabilization
DPOF	Digital Print Order Format
EV	Exposure Value
ISO	International Organization for Standardization
OIS	Optical Image Stabilization
WB	White Balance

Expressions used in this manual

Pressing the shutter

- Half-press [Shutter]: press the shutter halfway down
- Press [Shutter]: press the shutter all the way down



Subject, background, and composition

- Subject: the main object in a scene, such as a person, animal, or still life
- · Background: the objects around the subject
- Composition: the combination of a subject and background



Exposure (Brightness)

The amount of light that enters your camera determines the exposure. You can alter the exposure with shutter speed, aperture value, and ISO sensitivity. By altering the exposure, your photos will be darker or lighter.





Normal exposure

Overexposure (too bright)

Basic troubleshooting

Learn to solve common problems by setting shooting options.

10	The subject's eyes appear red.	Red eye occurs when the subject's eyes reflect light from the camera flash. • Set the flash option to Red-eye or Red-eye Fix. (p. 55) • If the photo has already been captured, select Red-eye Fix in the edit menu. (p. 96)
	Photos have dust spots.	If dust particles are present in the air, you may capture them in photos when you use the flash. Turn off the flash or avoid capturing photos in a dusty place. Set ISO sensitivity options. (p. 57)
*	Photos are blurred.	Blurring can occur if you capture photos in low light conditions or hold the camera incorrectly. Use the OIS function or half-press [Shutter] to ensure the subject is focused. (p. 29) Use the DUAL IS mode. (p. 35)
	Photos are blurred when shooting at night.	As the camera tries to let in more light, the shutter speed slows. This can make it difficult to hold the camera steady long enough to take a clear picture and may result in camera shake. • Select Night Shot mode. (p. 37) • Turn on the flash. (p. 55) • Set ISO sensitivity options. (p. 57) • Use a tripod to prevent your camera from shaking.
2)	Subjects come out too dark because of backlighting.	When the light source is behind the subject or when there is a high contrast between the light and dark areas, the subject may appear too dark. • Avoid shooting toward the sun. • Select Backlight in Scene mode. (p. 36) • Set the flash option to \$^F Fill in . (p. 55) • Adjust the exposure. (p. 67)
		 Set the Auto Contrast Balance (ACB) option. (p. 68) Set the metering option to Spot if a bright subject is in the center of the frame. (p. 68)

Quick reference



Capturing photos of people

- . Beauty Shot mode ▶ 37
- Red-eye/Red-eye Fix (to prevent or correct red-eye) ▶ 55
- Face Detection ▶ 62



Capturing photos at night or in the

- · Scene mode > Sunset, Dawn ▶ 36
- Night Shot mode ► 37
- Flash options ▶ 55
- ISO sensitivity (to adjust the sensitivity to light) ▶ 57



Capturing action photos

Continuous, Motion Capture ► 71



Adjusting the exposure (brightness)

- ISO sensitivity (to adjust the sensitivity to light) \blacktriangleright 57
- EV (to adjust exposure) ▶ 67
- ACB (to compensate for subjects against bright backgrounds) ► 68
- Metering ▶ 68
- AEB (to take 3 photos of the same scene with different exposures) ► 71



Capturing photos of text, insects, or flowers

- Scene mode > Text ▶ 36
- Close Up mode ► 36
- Macro ▶ 58



Applying effects to photos

- Object Highlight mode ► 42
- · Magic Frame shot mode ▶ 43
- Photo Filter mode ► 43
- Vignetting mode ▶ 46
- Smart Filter effects ▶ 72
- Image Adjust (to adjust Sharpness, Contrast, or Saturation) ► 75



Applying effects to videos

- Movie Filter mode ► 45
- · Vignetting mode ▶ 46
- Palette Effect Shot mode ▶ 47



Reducing camera shake

- · Optical Image Stabilization (OIS) ▶ 29
- DUAL IS mode ▶ 35

- Viewing files by category in Smart album ► 83
- Viewing files in 3D view ▶ 84
- Viewing files as thumbnails
 85
- Deleting files on the memory card ► 86
- Viewing files as a slide show
 ▶ 88
- Viewing files on a TV or HDTV
 ▶ 97
- Connecting your camera to a computer ▶ 99
- Adjusting sound and volume
 ▶ 109
- Adjusting the brightness of the display ► 110
- Changing the display language ► 111
- Setting the date and time
 ▶ 111
- Before contacting a service center ▶ 124

Contents

Basic functions	12
Unpacking	13
Camera layout	14
Inserting the battery and memory card	16
Charging the battery and turning on your camera	17
Charging the battery	17
Turning on your camera	17
Performing the initial setup	18
Learning icons	20
Using the touch screen	21
Setting the touch screen and sound	23
Setting the display type for the touch screen	23
Setting the sound	23
Using the Home screen	24
Accessing the Home screen	24
Icons on the Home screen	24
Rearranging icons	25
Capturing photos	26
Zooming	27
Reducing camera shake (OIS)	29
Tips for getting a clearer photo	30

Contents

50
51
51
52
54
55
55
55
57
58
58
59
60
60

Using face detection	62
Detecting faces	62
Capturing a self portrait shot	63
Capturing a smile shot	63
Detecting eye blinking	64
Using Smart Face Recognition	64
Registering faces as your favorites (My Star)	65
Adjusting brightness and color	67
Adjusting the exposure manually (EV)	67
Compensating for backlighting (ACB)	68
Changing the metering option	68
Selecting a light source (White balance)	69
Using burst modes	7-
Applying effects/Adjusting images	
Applying Smart Filter effects	
Adjusting your photos	
Reducing the sound of the zoom	
Available shooting options by shooting mode	

Playback/Editing	79
Viewing photos or videos in Playback mode	80
Starting Playback mode	80
Viewing photos	87
Playing a video	89
Playing a voice memo	91
Editing a photo	92
Resizing photos	92
Rotating a photo	93
Using Smart Crop	93
Applying Smart Filter effects	94
Adjusting your photos	94
Creating a print order (DPOF)	96
Viewing files on a TV or HDTV	97
Transferring files to your Windows computer	99
Transferring files with Intelli-studio	00
Transferring files by connecting the camera	
as a removable disk1	02
Disconnecting the camera (for Windows XP) 1	03
Transferring files to your Mac computer 1	04
Printing photos with a PictBridge photo printer 1	05

Settings	 10
Settings menu	 10
Accessing the settings menu	 10
Sound	 10
Display	 10
Connectivity	 110
General	 11
Appendixes	 11
Error messages	 11
Camera maintenance	 11
Cleaning your camera	 11
Using or storing the camera	 11
About memory cards	 11
About the battery	 12
Before contacting a service center	 12
Camera specifications	 12
Glossary	 13
FCC notice	 13
Index	 13

Basic functions

Learn about your camera's layout, icons, and basic functions for shooting.

Unpacking13	
Camera layout 14	
Inserting the battery and memory card 16	
Charging the battery and turning	
on your camera 17	
Charging the battery	
Turning on your camera	
Performing the initial setup	
Learning icons	
Using the touch screen	

Setting the touch screen and sound	23
Setting the display type for the touch screen Setting the sound	
Using the Home screen	24
Accessing the Home screen	24
Icons on the Home screen	24
Rearranging icons	25
Capturing photos	26
Zooming	27
Reducing camera shake (OIS)	29
Tips for getting a clearer photo	30

Unpacking

The following items are included in your product box.







Touch pen


Quick Start Manual




User Manual CD-ROM

Camera layout


Before you start, familiarize yourself with your camera's parts and their functions.






Inserting the battery and memory card


Learn how to insert the battery and an optional memory card into the camera.



Removing the battery and memory card



Push the card gently until it disengages from the camera, and then pull it out of the slot.



Slide the lock left to release the battery.




You can use the internal memory for temporary storage if a memory card is not inserted

Charging the battery and turning on your camera

Charging the battery

Before you use the camera for the first time, you must charge the battery. Attach the USB cable to the AC adapter, and then plug the end of cable with the indicator light into your camera.



Indicator light

- · Red: Charging
- · Orange: Error
- · Green: Fully charged

Turning on your camera


Press [POWER] to turn your camera on or off.

• The initial setup screen appears when you turn on the camera for the first time. (p. 18)



Turning on your camera in Playback mode

Press [Playback]. The camera turns on and immediately accesses Playback mode.





If you turn on your camera by pressing and holding [**Playback**] for about 5 seconds, the camera does not emit any sounds.

Performing the initial setup

When the initial setup screen appears, follow the steps below to configure the camera's basic settings.

1 Touch Language.



2 Select a language, and then touch **0K**.



3 Touch Time Zone.

- 4 Touch Home, and then touch ✓ or ➤ to select a time zone.
 - When you travel to another country, touch Visit, and then select a new time zone.



- 5 Touch **OK** to save.
- 6 Touch Date/Time Set.

7 Touch the up or down arrows to set the date.



8 Touch 1, and then set the time.



- To set daylight-saving time, touch 🐆
- 9 Touch OK to save.

- 10 Touch Touch Calibration.
- 11 Touch the target on the screen with your touch pen.



Touch directly in the center of the target for optimal performance.

12 Touch **OK** to save settings.

Learning icons

The icons the camera displays on the screen change according to the mode you select or the options you set.



Option icons (touch)

Icon	Description
≴ 8	Flash option
Euro]	Auto focus option
69	Timer option
MENU	Shooting options
	Display type

Status icons

Icon	Description	
(D)	Shooting mode	
2011/01/01	Current date	

	Description
10:00 AM	Current time
F3.3	Aperture value
1/45 S	Shutter speed
•	Voice memo
69	Timer
	Auto focus frame
IIШII	Camera shake
X5.5	Zoom indicator
X5.5	Zoom ratio
16m	Photo resolution when Intelli zoom is on
#	Grid lines

Status icons

Icon	Description
1	Available number of photos
00:05	Available recording time
100	Memory card not inserted (Internal memory)

Icon	Description
	Memory card inserted
(111)	IIII: Fully charged Partially charged Empty (Recharge)
2m	Photo resolution
1280 HQ	Video resolution
	Metering
OIS	Optical Image Stabilization (OIS)
Z	Exposure value adjusted
150 80	ISO sensitivity
A	White balance
	Burst type
4 ⁸	Flash
Q	Intelli zoom is on
	Smart Filter
[VII]	Image Adjust
[8]	Face detection
	Auto focus

Using the touch screen

Learn how to use the touch screen. Use the supplied touch pen to touch or drag on the screen.



Do not use sharp objects, such as pens or pencils, to touch the screen. You can damage the screen.

Touching

Touch an icon to select a menu or option.




Flicking

Gently flick the touch pen across the screen.




Dragging

Touch and hold a part of the screen, and then drag the touch pen.



Selecting an option

Drag the option list up or down until you find the desired option.
 Touch the option, and then touch OK.



 If an option has a setting button, touch the button to turn it on or off.





- The touch screen may not recognize your inputs if you touch multiple items at the same time.
- The touch screen may not recognize your inputs if you touch the screen with your finger.
- When you touch or drag the screen, discolorations may occur. This is not a malfunction, but a characteristic of the touch screen. Touch or drag lightly to minimize the effect.
- The touch screen may not work properly if you use the camera in extremely humid environments.
- The touch screen may not work properly if you apply screen protection film or other accessories to the screen.
- Depending on the viewing angle, the screen may appear dim. Adjust the brightness or viewing angle to improve the resolution.

Setting the touch screen and sound

Learn how to change the basic screen display and the sound settings.

Setting the display type for the touch screen

You can select from three screen display types Each displays differently.

- 1 In Shooting mode, touch III.
- 2 Select an option, and then touch **OK**.



ı		Description
		Full: Icons are always displayed.
		Hide: Icons are hidden if you perform no operation for 5 seconds (touch the screen to display the icons again).
	I⊞I	Guide Line: Grid lines are displayed. The grid lines are helpful for getting the photo aligned with a surface, such as the horizon or the edges of buildings.

Setting the sound

Set your camera to emit or not to emit a sound when you perform functions.


- 1 On the Home screen, touch .
- 2 Touch Sound.
- 3 Touch the setting button next to Beep Sound to turn on or off the beep.

Using the Home screen

You can select a shooting mode or access the settings menu by touching the icons on the Home screen.

Accessing the Home screen

In Shooting or Playback mode, press [HOME]. Press [HOME] again to return to the previous mode.





	Description
0	Touch an icon to access a mode or function. Scroll to another page by dragging or flicking the touch pen on the screen.
2	The number of the current page, (1) (2) (3)

Icons on the Home screen

	Description
9 2	Smart Auto: Capture a photo using a scene mode selected automatically by the camera. (p. 33)
P	Program : Capture a photo using manually setting options. (p. 38)
SCN	Scene : Capture a photo using options that are preset for a specific scene. (p. 36)
5	Smart Movie: Record a video using a scene mode selected automatically by the camera. (p. 40)
	Movie: Record a video. (p. 39)
	Photo Editor: Edit photos with various effects. (p. 94)
38aa	Album: View files by category in Smart album. (p. 83)
\otimes	Settings: Adjust settings to match your preferences. (p. 108)
	Vignetting: Capture a photo or record a video with a vignetting effect. (p. 46)
10	Beauty Shot : Capture a portrait with options to hide facial imperfections. (p. 37)
	Magic Frame shot: Capture a photo with various frame effects. (p. 43)

con	Description
6	Photo Filter : Capture a photo with various filter effects. (p. 43)
	Movie Filter : Record a video with various filter effects. (p. 45)
*)	Night Shot: Capture a night scene using a shutter speed and and aperture value set automatically by the camera. (p. 37)
	Palette Effect Shot: Record a video with palette effects. (p. 47)
*	Close Up: Capture close-up photos of subjects. (p. 36)
	Simple Shot : Capture a photo with simple adjustments to brightness and color. (p. 34)
(3)	Object Highlight : Capture a photo with the subject's background blurred. (p. 42)
	3D Album: View files with 3D effects. (p. 84)
	Slide Show: View photos as a slide show with effects and music. (p. 88)
•	Voice Recorder: Record and save a voice memo. (p. 48)
	Magazine View: View files with page flip effect. (p. 84)
	DUAL IS: Reduce camera shake both optically and digitally to prevent blurred photos. (p.35)

Rearranging icons

You can rearrange the icons on the Home screen in any order.

1 Touch and hold an icon.



2 Drag it to a new location.

 To move an icon to another page, drag it to the left or right edge of the screen. When you drop the icon to a new location, the other icons will neatly slide out of the way.



Capturing photos

Learn how to capture photos easily and quickly in Smart Auto mode.


1 On the Home screen, touch



2 Align your subject in the frame.



- 3 Half-press [Shutter] to focus.
 - · A green frame means the subject is in focus.
 - · A red frame means the subject is out of focus.



4 Press [Shutter] to capture a photo.




See page 30 for tips to get clearer photos.

Zooming

You can capture close-up photos by adjusting the zoom. Your camera has a 5X Optical zoom, 2X Intelli zoom, and 5X Digital zoom. The Intelli zoom and Digital zoom cannot be used at the same time.



Zoom ratio






The available zoom ratio for videos differs from photo zoom ratio.

Digital zoom

If the zoom indicator is in the digital range, your camera is using the Digital zoom. By using both the Optical zoom and Digital zoom, you can zoom in up to 25 times.






- The Digital zoom is available only in Program and Scene (except Text) modes.
- The Digital zoom is not available with a Smart Filter effect or Smart Touch AF option.
- If you capture a photo with the Digital zoom, the photo quality may deteriorate.

Intelli zoom

If the zoom indicator is in the Intelli range, your camera is using the Intelli zoom. Photo resolution varies by how much you have zoomed in if you use the Intelli zoom. By using both the Optical zoom and Intelli zoom, you can zoom in up to 10 times.





- The Intelli zoom is available only in the Smart Auto, Program, and Scene (except Text) modes.
- The Intelli zoom is not available when you use a Smart Filter effect or the Smart Touch AF option.
- The Intelli zoom automatically turns on when you select the 4:3 aspect ratio. You can use the Digital zoom instead of the Intelli zoom by turning off the Intelli zoom. Intelli zoom is not available when you select the 16:9 aspect ratio.
- The Intelli zoom helps you capture a photo with less quality deterioration than the Digital zoom. However, the photo quality may be lower than when you use the Optical zoom.

Setting Intelli zoom

- 1 In Shooting mode, touch
- 2 Touch the setting button next to Intelli Zoom.

Reducing camera shake (OIS)

Reduce camera shake optically in Shooting mode.





Before correction

After correction


- 1 In Shooting mode, touch MENU.
- 2 Touch the setting button next to OIS.





- · OIS may not function properly when:
 - you move your camera to follow a moving subject
 - you use the Digital zoom
 - there is too much camera shake
 - the shutter speed is slow (for example, when you capture night scenes)
 - the battery is low
 - you capture a close-up shot
- If you use the OIS function with a tripod, the vibration of the OIS sensor may blur your images. Deactivate the OIS function when you use a tripod.
- If the camera is hit or dropped, the display will be blurry. If this occurs, turn off the camera, and then turn it on again.

Tips for getting a clearer photo





Ensure nothing is blocking the lens.

Half-pressing the shutter button



Half-press [Shutter] to adjust the focus. The camera adjusts the focus and exposure automatically.

The camera sets the aperture value and shutter speed automatically.

Focus frame

- Press [Shutter] to capture the photo if the focus frame appears in green.
- Change the composition and half-press [Shutter] again if the focus frame appears in red.

Reducing camera shake



- Set the Optical Image Stabilization option to reduce camera shake optically. (p. 29)
- Select the DUAL IS mode to reduce camera shake both optically and digitally. (p.35)

When who is displayed



Camera shake

When you shoot in the dark, avoid setting the flash option to **Slow Sync** or **Off**. The aperture remains open longer and it may be harder to hold the camera steady long enough to take a clear picture.

- Use a tripod or set the flash option to Fill in. (p. 55)
- Set ISO sensitivity options. (p. 57)



Preventing your subject from being out of focus


It may be difficult to get your subject in focus when:


- there is little contrast between the subject and background (for example, when your subject is wearing clothing that is similar in color to the background)
- the light source behind the subject is too bright
- the subject is shiny or reflective
- the subject includes horizontal patterns, such as blinds
- the subject is not positioned in the center of the frame



Using the focus lock

Half-press [Shutter] to focus. When the subject is in focus, you can reposition the frame to change the composition. When you are ready, press [Shutter] to capture your photo.





· When you capture photos in low light



Turn on the flash. (p. 55)

· When subjects are moving rapidly



Use the Continuous or Motion Capture function. (p. 71)

Extended functions

Learn how to capture a photo, record a video, and record a voice memo by selecting a mode.

Using shooting modes	Using effect modes
Using the Smart Auto mode	Using the Object Highlight mode
Using the Simple Shot mode	Using the Magic Frame Shot mode
Using the DUAL IS mode	Using the Photo Filter mode
Using the Scene mode	Using the Movie Filter mode
Using the Close Up mode	Using the Vignetting mode
Using the Night Shot mode	Using the Palette Effect mode
Using the Beauty Shot mode	Recording voice memos
Using the Program mode	Recording a voice memo
Using the Movie mode	Adding a voice memo to a photo
Using the Smart Movie mode	

. 42 . 43 . 43 . 45 . 46 . 47 . 48 . 48

Using shooting modes

Capture photos or record videos by selecting the best shooting mode for the conditions.

Using the Smart Auto mode

In Smart Auto mode, your camera automatically chooses the appropriate camera settings based on the type of scene it detects. The Smart Auto mode is helpful if you are not familiar with the camera settings for various scenes.

- 1 On the Home screen, touch <a>§.
- 2 Align your subject in the frame.
 - The camera automatically selects a scene and adjusts its settings. An appropriate scene icon appears at the top left of the screen. The icons are listed below.



Icon	Description
<u> </u>	Landscapes
WHITE	Scenes with bright white backgrounds
*)	Landscapes at night (when the flash is off)

	Description
1	Portraits at night
*	Landscapes with backlighting
*	Portraits with backlighting
	Portraits
*	Close-up photos of objects
**	Close-up photos of text
	Sunsets
	Clear skies
<u> </u>	Forested areas
	Close-up photos of colorful subjects
昂	Camera is stabilized or on a tripod (when shooting in the dark)
<i>**</i> ***	Actively moving subjects
*	Fireworks (when using a tripod)

- 3 Half-press [Shutter] to focus.
 - In several scenes, the camera automatically captures a photo when you half-press [Shutter].
- 4 Press [Shutter] to capture the photo.



- If the camera does not recognize an appropriate scene mode, it uses the default settings for the Smart Auto mode.
- Even if it detects a face, the camera may not select a portrait mode depending on the subject's position or lighting.
- The camera may not select the correct scene depending on the shooting conditions, such as camera shake, lighting, or distance to the subject.
- Even if you use a tripod, the camera may not detect the mode if the subject is moving.
- In Smart Auto mode, the camera consumes more battery power, because it changes settings often to select appropriate scenes.

Using the Simple Shot mode

In Simple Shot mode, you can capture photos with simple adjustments to brightness and color.

- 1 On the Home screen, touch 3.
- 2 Drag the sliders or touch the sample photos to adjust Brightness and Color.



- 3 Align your subject in the frame, and then half-press [Shutter] to focus.
- 4 Press [Shutter] to capture the photo.

Using the DUAL IS mode

Reduce camera shake and prevent blurred photos with Optical and Digital Image Stabilization functions.






Before correction

After correction

1 On the Home screen, touch ...



2 Align your subject in the frame, and then half-press [Shutter] to focus.

3 Press [Shutter] to capture the photo.



- The Digital zoom and Intelli-zoom are not available in DUAL IS mode.
- The camera will optically correct photos only when the light source is brighter than fluorescent light.
- · If your subject is moving rapidly, the photo may be blurry.
- Set the Optical Image Stabilization option to reduce camera shake in different shooting modes. (p. 29)

Using the Scene mode

In Scene mode, you can capture a photo with options that are preset for a specific scene.

- 1 On the Home screen, touch ...
- 2 Touch a scene.



- 3 Align your subject in the frame, and then half-press [Shutter] to focus.
- 4 Press [Shutter] to capture the photo.

Using the Close Up mode

In Close Up mode, you can capture close-up photos of subjects, such as flowers or insects.

1 On the Home screen, touch ...




- 2 Align your subject in the frame, and then half-press [Shutter] to focus.
- 3 Press [Shutter] to capture the photo.

Using the Night Shot mode

In Night mode, you can use a slow shutter speed to extend the time the shutter stays open. Increase the aperture value to prevent overexposure.

- 1 On the Home screen, touch 2
- 2 Drag the dials on the screen in the arrow directions below to adjust shutter speed and aperture value.



- 3 Align your subject in the frame, and then half-press [Shutter] to focus.
- 4 Press [Shutter] to capture the photo.




Use a tripod to prevent blurry photos.

Using the Beauty Shot mode

In Beauty Shot mode, you can capture a portrait with options to hide facial imperfections.

- On the Home screen, touch 🐚.
- 2 Drag the sliders or touch the sample photos to adjust the Face Tone and Face Retouch.
 - For example, increase the Face Tone setting to make skin appear lighter.



- 3 Align your subject in the frame, and then half-press [Shutter] to focus.
- 4 Press [Shutter] to capture the photo.




When using the Beauty Shot mode, the focus distance will be set to Auto Macro.

Using the Program mode

In Program mode, you can set most options, except the shutter speed and aperture value, which the camera sets automatically.

- 1 On the Home screen, touch 10.
- 2 Touch , and then set desired options. (For a list of options, refer to page 50.)



- 3 Align your subject in the frame, and then half-press [Shutter] to focus.
- 4 Press [Shutter] to capture the photo.

Setting My screen

In Program mode, you can add shortcuts for your favorite options to the left side of the screen.


- 1 In Shooting mode, touch \longrightarrow My screen \rightarrow 0K.
- 2 Touch and hold one of the icons on the right.



- 3 Drag the icon into a desired box on the left.
 - · To remove shortcuts, drag an icon to the right.



4 Touch **OK** to save.





You can create up to 3 shortcuts.

Using the Movie mode


In Movie mode, you can record high-definition videos of up to 20 minutes in length. The camera saves recorded videos as MP4 (H.264) files.



- H.264 (MPEG-4 part10/AVC) is a high-compression video format established by the international standard organizations ISO-IEC and ITU-T.
- Some memory cards may not support high definition recording. If this
 occurs, set a lower resolution.
- Memory cards with slow write speeds will not support high-resolution videos and high-speed videos. To record high-resolution or highspeed videos, use memory cards with faster write speeds.
- If you have activated Optical Image Stabilization, the camera may record the sounds the OIS makes when it operates.
- 1 On the Home screen, touch .
- 2 Touch , and then set desired options. (For a list of options, refer to page 50.)
- 3 Press [Shutter] or touch to start recording.
- 4 Press [Shutter] again or touch to stop recording.

Pause recording

The camera allows you to temporarily pause a video while recording. With this function, you can record separate scenes as a single video.




- Touch II to pause while recording.
- Touch to resume.

Using the Smart Movie mode

In Smart Movie mode, your camera automatically chooses the appropriate camera settings based on the scene it has detected.

- 2 Align your subject in the frame.
 - The camera automatically selects a scene and adjusts its settings. An appropriate scene icon appears at the top left of the screen. The icon are listed below.



Icon	Description
<u></u>	Landscapes
	Sunsets
<u></u>	Clear skies
<u></u>	Forested areas

- 3 Press [Shutter] or touch to start recording.
- 4 Press [Shutter] again or touch to stop recording.



- If the camera does not recognize an appropriate scene mode, it uses the default settings for Smart Movie mode.
- The camera may not select the correct scene depending on the shooting conditions, such as camera shake, lighting, and distance to the subject.
- · Smart Filter effects are not available in Smart Movie mode.


Using effect modes

Capture photos or record videos with various effects.

Using the Object Highlight mode

The Object Highlight mode makes the subject more discernible by adjusting the depth of field.

- 1 On the Home screen, touch 1
- 2 Position the camera according to the optimum distance displayed on the screen.
 - The optimum distance will vary, based on the zoom ratio you use.
- 3 Drag the sliders or touch the sample photos to adjust Blur and Tone.



4 Half-press [Shutter] to focus.

- When the camera can apply the Object Highlight effect,
 will appear.
- When the camera cannot apply the Object Highlight effect,
 will appear. If this occurs, adjust the distance from the camera to the subject.
- 5 Press [Shutter] to capture the photo.



- Available resolutions in Object Highlight mode are 3m and 1m.
- If the shooting distance is not within the optimum range, you can capture a photo but the Object Highlight effect will not be applied.
- . The Object Highlight effect cannot be used in dark places.
- The Object Highlight effect cannot be used with the Optical zoom at 3X or higher.
- · Digital zoom is not available in Object Highlight mode.
- Use a tripod to prevent camera shake as the camera captures 2 consecutive photos to apply the effect.
- The subject and the background should have a significant contrast in color.
- Subjects should be positioned far away from the background for the greatest effect.

Using the Magic Frame Shot mode

In Magic Frame Shot mode, you can apply various frame effects to your photos. The shape and the feel of the photos will change according to the frame you select.

- 1 On the Home screen, touch .
- 2 Select a desired frame.



- 3 Align your subject in the frame, and then half-press [Shutter] to focus.
- 4 Press [Shutter] to capture the photo.



In Magic Frame Shot mode, the resolution is automatically set to 2.

Using the Photo Filter mode

In Photo Filter mode, you can apply various filter effects to your photos.





Miniature

Vignetting





Fish-eve

Sketch

- 1 On the Home screen, touch .
- 2 Touch a desired filter.
 - · To view the original photo, touch Before.
 - To view the photo with the filter effect, touch After.



Option	Description
Miniature	Apply a tilt-shift effect to make the subject appear in miniature.
Vignetting	Apply the retro-looking colors, high contrast, and strong vignette effect of Lomo cameras.
Soft-Focus	Hide facial imperfections or apply dreamy effects.
Old Film 1	Apply vintage film effect 1.
Old Film 2	Apply vintage film effect 2.
Half Tone Dot	Apply a halftone effect.
Sketch	Apply a pen sketch effect.

Option	Description
Fish-eye	Blacken the edges of the frame and distort objects to imitate the visual effect of a fisheye lens.
Defog	Make a photo clearer.
Classic	Apply a black and white effect.
Retro	Apply a sepia tone effect.
Negative	Apply a negative film effect.

- 3 Align your subject in the frame, and then half-press [Shutter] to focus.
- 4 Press [Shutter] to capture the photo.



- To apply filter effects to saved photos, touch 2.
 When you select **Sketch**, the resolution will change to 5m and below.

Using the Movie Filter mode

In Movie Filter mode, you can record videos with various filter effects

- 1 On the Home screen, touch 2.
- 2 Touch a desired filter.



Option	Description
Miniature	Apply a tilt-shift effect to make the subject appear in miniature.
Vignetting	Apply the retro-looking colors, high contrast, and strong vignette effect of Lomo cameras.
Half Tone Dot	Apply a halftone effect.
Sketch	Apply a pen sketch effect.

Option	Description
Fish-eye	Distort close objects to imitate the visual effect of a fisheye lens.
Defog	Make the image clearer.
Classic	Apply a black and white effect.
Retro	Apply a sepia tone effect.
Negative	Apply a negative film effect.

- 3 Press [Shutter] or touch to start recording.
- 4 Press [Shutter] again or touch to stop recording.



- If you select Miniature, the speed of the video will increase.
- If you select Miniature, the camera will not record sound.
- If you select Miniature, Vignetting, Half Tone Dot, Sketch, Fish-eye, or Defog, the recording speed will be set to \(\mathbb{g}\)! and the recording resolution will be set to less than 640.


Using the Vignetting mode

In Vignetting mode, you can capture a photo or record a video with a vignetting effect.

- 1 On the Home screen, touch .
- 2 Select (photo) or (movie).
- 3 Drag the sliders or touch the sample photos to adjust Level, Brightness, and Contrast.
 - · To view the original photo, touch Before.
 - · To view the photo with the vignetting effect, touch After.



- 4 Align your subject in the frame, and then half-press [Shutter] to focus.
- 5 Press [Shutter] to capture the photo.



Using the Palette Effect mode

In Palette Effect mode, you can record a video with effects to make specific colors stand out.

- 1 On the Home screen, touch .
- 2 Touch a desired palette.



Option	Description
Palette Effect 1	Create a vivid look with sharp contrast and red color.
Palette Effect 2	Make scenes clean and clear by applying a soft blue tone.
Palette Effect 3	Apply a soft brown tone.
Palette Effect 4	Create a cold and monotone effect.

- 3 Press [Shutter] or touch to start recording.
- 4 Press [Shutter] again or touch to stop recording.

Recording voice memos

Learn how to record a voice memo that you can play back later. You can also add a voice memo to a photo to remind you of shooting conditions.



You will get the best sound quality when you speak 16 in (40 cm) away from the camera.

Recording a voice memo

- 1 On the Home screen, touch ...
- 2 Press [Shutter] or touch to start recording.
 - . Touch II to pause or touch to resume.
 - Each memo can be up to 10 hours long if memory is available.



3 Press [Shutter] again or touch ■ to stop recording.




To view the list of saved voice memos, touch ...

Adding a voice memo to a photo

In Program mode, you can add a voice memo to a captured photo.

- 1 On the Home screen, touch 10.
- 2 Touch , and then touch the setting button next to Memo.
- 3 Align your subject in the frame, and then capture a photo.
 - The camera begins to record a voice memo right after you capture the photo.



- 4 Record a short voice memo (10 seconds maximum).
 - Press [Shutter] to stop recording a voice memo before the 10 seconds are up.



You cannot add voice memos to photos in the burst mode.

Shooting options

Learn how to set the options in Shooting mode.

Selecting a resolution and quality 5 Selecting a resolution 5 Selecting image quality 5	Using Smart Fac
Using the timer 5	54 (My Star)
Shooting in the dark 5 Preventing red-eye 5 Using the flash 5 Adjusting the ISO sensitivity 5	Adjusting brightne Adjusting the exp Compensating for
Changing the camera's focus 5 Using macro 5 Using smart touch focus 5 Using one touch shooting 6 Adjusting the focus area 6	Selecting a light s Using burst mode: Applying effects/A Applying Smart F
Using face detection 6 Detecting faces 6 Capturing a self portrait shot 6 Capturing a smile shot 6	Reducing the sour Available shooting by shooting mode

Detecting eye blinking	64
Using Smart Face Recognition	64
Registering faces as your favorites	
(My Star)	65
Adjusting brightness and color	67
Adjusting the exposure manually (EV)	67
Compensating for backlighting (ACB)	68
Changing the metering option	68
Selecting a light source (White balance)	69
Using burst modes	71
Applying effects/Adjusting images	72
Applying Smart Filter effects	72
Adjusting your photos	75
Reducing the sound of the zoom	76
Available shooting options	
by shooting mode	77

Selecting a resolution and quality

Learn how to change the image resolution and quality settings.

Selecting a resolution

As you increase the resolution, your photo or video will include more pixels so it can be printed on larger paper or displayed on a larger screen. When you use a high resolution, the file size will also increase.

Setting the photo resolution

- 1 In Shooting mode, touch MENU → Photo Size.
- 2 Select an option, and then touch **OK**.



Icon	Description
16m	4608 X 3456 : Print on A1 paper.
₫Ч m	4608 X 3072: Print on A1 paper in wide ratio (3:2).
	4608 X 2592: Print on A1 paper in panorama ratio (16:9) or play back on an HDTV.
IOm	3648 X 2736 : Print on A2 paper.
Sm	2592 X 1944: Print on A4 paper.
3m	1984 X 1488: Print on A5 paper.
2m	1920 X 1080: Print on A5 paper in panorama ratio (16:9) or play back on an HDTV.
lm	1024 X 768: Attach to an email.

Setting the video resolution

- 1 In Shooting mode, touch **MOVIE Size**.
- 2 Select an option, and then touch **OK**.



Ico		Description	
12	280 HQ	1280 X 720 HQ: Play back high-quality files on an HDTV.	
12	280	1280 X 720: Play back on an HDTV.	
6	40	640 X 480: Play back on an analog TV.	
3	20	320 X 240 : Post on a web page.	

Selecting image quality

Set the photo and video quality settings. Higher image quality settings will result in larger file sizes.

Setting the photo quality

The camera compresses and saves the photos you capture in the JPEG format.

- 1 In Shooting mode, touch Quality.
- 2 Select an option, and then touch **OK**.



	Description
SF	Super Fine: Capture photos in super high quality.
∞	Fine: Capture photos in high quality.
⊗ n	Normal: Capture photos in normal quality.

Setting the video quality

The camera compresses and saves the videos you record in the MP4 $\left(\text{H}.264\right)$ format.

- 1 In Shooting mode, touch → Frame Rate.
- 2 Select an option, and then touch **OK**.
 - As the frame rate increases, action appears more natural, but the file size also increases.




Icon	Description
30	30 FPS: Record 30 frames per second.
15	15 FPS: Record 15 frames per second.

Using the timer

Learn how to set the timer to delay shooting.

- 1 In Shooting mode, touch MENU → Timer.
- 2 Select an option, and then touch **OK**.



Icon	
₹ _{OFF}	Off: The timer is not active.
७ ₁0	10 Sec: Capture a photo after a 10-second delay.
ు ₂	2 Sec: Capture a photo after a 2-second delay.
త ^{్ర}	Double : Capture one photo after a 10-second delay and another photo after a 2-second delay.

Available options may differ depending on the shooting mode.

3 Press [Shutter] to start the timer.

 The AF-assist light/timer lamp blinks. The camera will automatically capture a photo at the specified time.



- · Press [Shutter] to cancel the timer.
- Depending on the Face Detection option you have selected, the timer function or some of its options may not be available.
- Self timer options are not available if you set burst options.

Shooting in the dark

Learn how to capture photos at night or in low light conditions.

Preventing red-eye

If the flash fires when you capture a photo of a person in the dark, a red glow may appear in the person's eyes. To prevent this, select **Red-eye** or **Red-eye Fix**. Refer to flash options in "Using the flash."








This option is available in Program, Beauty Shot, and Night Shot modes.

Using the flash

Use the flash when you capture photos in the dark or when you need more light in your photos.

- 1 In Shooting mode, touch MIN → Flash.
- 2 Select an option, and then touch **OK**.



Icon	Description
③	The flash will not fire. The camera will display the shake warning when you are shooting in low light.
≴ B	Auto : The flash will fire automatically when the subject or background is dark.

Red-eye: . The flash will fire twice when the subject or background is dark to reduce the red-eye effect. **①** . There is an interval between 2 bursts of the flash. Do not move until the flash fires a second time. Fill in: · The flash always fires. The camera automatically adjusts the flash's intensity. Slow Sync: · The flash fires and the shutter stays open longer. . This option is recommended when you want to capture ambient light to reveal more details in the **4**,s background. · Use a tripod to prevent your photos from blurring. • The camera will display the shake warning when you are shooting in low light. Red-eye Fix: . The flash fires twice when the subject or background is dark, and the camera corrects red-eyes through its de advanced software analysis. . There is an interval between 2 bursts of the flash. Do not move until the flash fires a second time.

Available options may differ depending on the shooting mode.



- Flash options are not available if you set burst options or select Self-Portrait or Blink Detection.
- Make sure that your subjects are within the recommended distance from the flash. (p. 128)
- If light from the flash is reflected or there is a substantial amount of dust in the air, tiny spots may appear in your photo.

Adjusting the ISO sensitivity

The ISO sensitivity is the measure of a film's sensitivity to light as defined by the International Organization for Standardization (ISO). The higher ISO sensitivity you select, the more sensitive to light your camera becomes. With a higher ISO sensitivity, you can get a better photo without using the flash.

- 1 In Shooting mode, touch MENU → ISO.
- 2 Select an option, and then touch **OK**.
 - · Select Auto to have the camera select an appropriate ISO sensitivity automatically based on the brightness of the subject and lighting.





Higher ISO sensitivities may result in more image noise.

Changing the camera's focus

Learn how to adjust the camera's focus to suit the subject and the shooting conditions.


Using macro

Use macro to capture close-up photos of subjects, such as flowers or insects.



- Try to hold the camera firmly to prevent blurry photos.
- Turn off the flash if the distance to the subject is less than 16 in (40 cm).

- 1 In Shooting mode, touch → Focus.
- 2 Select Macro, and then touch OK.




Icon	Description
[eurg	Normal (AF): Focus on a subject farther than 32 in (80 cm) from the camera.
	Macro: Manually focus on a subject that is 2-32 in (5-80 cm) from the camera (39-59 in [100-150 cm] when you use the zoom).

Using smart touch focus

Smart Touch AF allows you to track and auto focus on your subject, even when you are moving.

- 1 In Shooting mode, touch Focus Area.
- 2 Select Smart Touch AF, and then touch OK.
- 3 Touch the subject you want to track in the touch area.



- The white frame means that your camera is tracking the subject.
- The green frame means that your subject is in focus when you half-press [Shutter].




- If you do not touch any area on the screen, the focus frame will appear in the center of the screen.
- · Tracking a subject may fail when:
 - the subject is too small
 - the subject moves excessively
 - the subject is backlit or you are shooting in a dark place
 - colors or patterns on the subject and the background are the same
 - the camera shakes excessively
- When tracking a subject fails, the focus frame will appear as a white single-line frame (
).
- If the camera fails to track the subject, you must reselect the subject to track.
- If the camera fails to focus, the focus frame will change to a red singleline frame ().
- If you use this function, you cannot set Self Timer options, Face Detection options, and Smart Filter options.

Using one touch shooting

You can focus on a subject and capture a photo with the touch of your finger.

- 1 In Shooting mode, touch ► Focus Area.
- Select One Touch Shooting, and then touch OK.
- 3 Touch a subject to capture the photo.





If you use this function, you cannot set Self Timer options, Burst options, and Smart Filter effects

Adjusting the focus area

You can get clearer photos by selecting an appropriate focus area according to your subject's location in the scene.

- 1 In Shooting mode, touch W→ Focus Area.
- 2 Select an option, and then touch **OK**.



Icon	Description
•	Center AF : Focus on the center of the frame (suitable when subjects are located at or near the center).
:::	Multi AF: Focus on one or more of 9 possible areas.
[6]	One Touch Shooting: Focus on the subject and capture a photo by touching the image on the screen. (p. 60)
	Smart Touch AF: Focus on and track the subject that you touch on the screen. (p. 59)

Using face detection

If you use Face Detection options, your camera can automatically detect a human face. When you focus on a human face, the camera adjusts the exposure automatically. Use **Blink Detection** to detect closed eyes or **Smile Shot** to capture a smilling face. You can also use **Smart Face Recognition** to register faces and prioritize the focus on them.



- . The camera automatically tracks the registered face.
- · Face Detection may not be effective when:
 - the subject is far from the camera (The focus frame will appear orange for Smile Shot and Blink Detection.)
 - it is too bright or too dark
 - the subject is not facing the camera
 - the subject is wearing sunglasses or a mask
 - the subject's facial expression changes drastically
 - the subject is backlit or the lighting conditions are unstable
- Face Detection is not available when you set Smart Filter effects or Smart Touch AF.
- Depending on the shooting options, available Face Detection options may differ.
- Depending on the Face Detection options you selected, the timer function may not be available or available timer options may differ.
- When you set Face Detection options, some Burst options are not available.
- When you capture photos of detected faces, they will be registered in the face list.
- You can view registered faces in order of priority in Playback mode.
 (p. 82) Even though faces are registered successfully, they may not be classified in Playback mode.
- A face detected in Shooting mode may not appear in the face list or Smart Album.

Detecting faces

Your camera automatically detects up to 10 human faces in one scene.

- 1 In Shooting mode, touch → Face Detection.
- 2 Select **Normal**, and then touch **OK**.



The nearest face appears in a white focus frame and the rest of the faces appear in gray focus frames.



- The closer you are to the subjects, the quicker your camera will detect faces.
- To focus on a subject in a gray focus frame, touch the face in the frame.
- The detected faces may not be registered if you set Burst options such as Continuous, Motion Capture, or AEB.

Capturing a self portrait shot

Capture photos of yourself. The focus distance will be set to close-up and your camera will emit a beep.

- 1 In Shooting mode, touch **▶ Face Detection**.
- 2 Select Self-Portrait, and then touch OK.
- 3 When you hear a quick beep, press [Shutter].



When faces are located in the center, the camera beeps rapidly.



If you turn **Volume** off in the sound settings, the camera will not emit a beep. (p. 109)

Capturing a smile shot

The camera automatically releases the shutter when it detects a smiling face.

- 1 In Shooting mode, touch **■** → **Face Detection**.
- 2 Select Smile Shot, and then touch OK.
- 3 Compose your shot.
 - The camera automatically releases the shutter when it detects a smilling face.





When your subject smiles broadly, your camera can detect the smile more easily.

Detecting eye blinking

If your camera detects closed eyes, it will automatically capture 2 photos in succession.

- 1 In Shooting mode, touch → Face Detection.
- 2 Select Blink Detection, and then touch OK.







If Blink Detection fails, the "Picture taken with eyes closed."
 message appears. Capture another photo.

Using Smart Face Recognition

The camera automatically registers faces that you frequently photograph. The Smart Face Recognition feature will automatically prioritize the focus on those faces and on favorite faces. The Smart Face Recognition feature is available only when you use a memory card.

- 1 In Shooting mode, touch **■■** → **Face Detection**.
- 2 Select Smart Face Recognition, and then touch **OK**.



The nearest face appears in a white focus frame and the rest of the faces appear in gray focus frames.

- —: Faces that you have registered as favorites.

 (To register faces as favorites, refer to page 65.)
- : Faces that the camera has automatically registered.



- The camera may recognize and register faces incorrectly depending on lighting conditions, drastic changes in the subject's pose or face, and whether or not the subject is wearing glasses.
- The camera can automatically register up to 14 faces. If the camera recognizes a new face when 14 faces have already been registered, it will replace the lowest priority face with the new one.
- . The camera can detect up to 5 favorite faces in one scene.

Registering faces as your favorites (My Star)

You can register your favorite faces to prioritize the focus and exposure on those faces. This feature is available only when you use a memory card.

- 1 In Shooting mode, touch → Smart FR Edit.
- 2 Select My Star, and then touch OK.
- 3 Align your subject's face with the oval guideline, and then press [Shutter] to register the face.





- If the subject's face is not aligned with the oval guideline, the white frame will not appear.
- Capture 5 photos of the subject's face: one each from the front, left, right, above, and below.
- · Capture photos of one person at a time when registering faces.

- 4 Touch **b** when the face list appears.
 - Your favorite faces are indicated with a * on the face list.



- You can register up to 6 favorite faces.
 - . The flash will not fire when you register a favorite face.
 - If you register the same face twice, you can delete one of the faces in the face list.

Viewing your favorite faces

- 1 In Shooting mode, touch → Smart FR Edit.
- 2 Select Face List, and then touch **OK**.



- To change the ranking of your favorite faces, touch 💏. (p. 82)
- To delete a favorite face, touch in.

Adjusting brightness and color

Learn how to adjust the brightness and color for better image quality.

Adjusting the exposure manually (EV)

Depending on the intensity of the ambient light, your photos may be too bright or dark. In these cases, you can adjust the exposure to get a better photo.








Dainei

Neutral (0)

Dilgillei (

- 1 In Shooting mode, touch \longrightarrow EV.
- 2 Select a desired value, and then touch **OK**.
 - · The photo will be brighter as exposure increases.
 - When you adjust the exposure value, the icon will appear as shown below.





- Once you adjust the exposure, the setting will be stored automatically.
 You may need to change the exposure value later to avoid overexposure or underexposure.
- If you cannot decide on an appropriate exposure, select AEB (Auto Exposure Bracket). The camera will capture 3 consecutive photos, each with a different exposure: normal, underexposed, and overexposed. (p. 71)

Compensating for backlighting (ACB)

When the light source is behind your subject or there is high contrast between your subject and the background, your subject is likely to appear dark in the photo. If this occurs, set the Auto Contrast Balance (ACB) option.





Without ACB

With ACB

- 1 In Shooting mode, touch MENU.
- 2 Touch the setting button next to ACB.






- The ACB feature is always on in Smart Auto, Scene (Beach & Snow) modes.
- The ACB feature is not available when you set Continuous, Motion Capture, or AEB options.

Changing the metering option

The metering mode refers to the way in which a camera measures the quantity of light. The brightness and lighting of your photos will vary depending on the metering mode you select.

- 1 In Shooting mode, touch ■■ → Metering.
- 2 Select an option, and then touch **OK**.



frame

	Description
lacksquare	Multi: Your camera divides the frame into several areas, and then measures the light intensity of each area. Suitable for general photos.
٠	Spot: Your camera measures only the light intensity of the very center of the frame. If a subject is not in the center of the frame, your photo may be improperly exposed. Suitable for a subject with backlighting.
©	Center-weighted: Your camera averages the meter reading of the entire frame with emphasis placed on the center. Suitable for photos with subjects in the center of the

Selecting a light source (White balance)

The color of your photo depends on the type and quality of the light source. If you want the color of your photo to be realistic, select a white balance setting that is appropriate for the lighting conditions, such as Auto WB, Daylight, Cloudy, or Tungsten.



S. Butter

Auto WB

Daylight





Cloudy

- 1 In Shooting mode, touch → White Balance.
- 2 Select an option, and then touch **OK**.




Icon	Description
FWD	Auto WB : Automatically set the White Balance based on the lighting conditions.
	Daylight: For outdoor photos on a sunny day.
A	Cloudy: For outdoor photos on a cloudy day or in shadows.
1	Fluorescent_H: For shooting under a daylight fluorescent or 3-way fluorescent light.
****	Fluorescent_L: For shooting under white fluorescent light.
:•	Tungsten: For shooting indoor photos under incandescent bulbs or halogen lamps.
	Custom Set : Use White Balance settings that you defined.

Defining your own White Balance

You can customize the White Balance by capturing a photo of a white surface, such as a piece of paper, under the lighting conditions in which you intend to capture a photo. The White Balance feature will help your camera reproduce the colors that are in the scene accurately in your photo.

- 1 In Shooting mode, touch → White Balance.
- 2 Select Custom Set, and then touch OK.
- 3 Aim the lens at a piece of white paper, and then press [Shutter].



Using burst modes

It can be difficult to capture photos of fast-moving subjects or capture natural facial expressions and gestures of your subjects in photos. In these cases, select one of the burst modes to capture multiple photos rapidly.



- 1 In Shooting mode, touch → Drive.
- 2 Select an option, and then touch **OK**.



Icon	Description
	Single: Capture a single photo.
	Continuous: While you are pressing [Shutter], the camera continuously captures photos. The maximum number of photos depends on the capacity of your memory card.
	Motion Capture: While you are pressing [Shutter], the camera captures VGA photos (6 photos per second; maximum of 30 photos).
(TET)	AEB: • Captures 3 consecutive photos, each with a different



You can use the flash, timer, ACB, and Smart Filter only when you select **Single**.

Use a tripod to prevent blurry photos.

 When you select Motion Capture, your camera will set the resolution to VGA and set the ISO sensitivity to Auto.

exposure: normal, underexposed, and overexposed.

 Depending on the Face Detection option you selected, some Burst options may not be available.

Applying effects/Adjusting images

Applying Smart Filter effects

Apply various filter effects to your photos and videos to create unique images.





Miniature

Vignetting

ART -

C

Fish-eye

Sketch

- 1 In Shooting mode, touch \longrightarrow Smart Filter.
- 2 Select a filter, and then touch **OK**.

Available filters in Program mode

con	Description
	Normal: No effect
•	Miniature : Apply a tilt-shift effect to make the subject appear in miniature.
(Vignetting: Apply the retro-looking colors, high contrast, and strong vignette effect of Lomo cameras.
	Soft-Focus : Hide facial imperfections or apply dreamy effects.
⊞Ō	Old Film 1: Apply vintage film effect 1.
⊞Ō	Old Film 2: Apply vintage film effect 2.
	Half Tone Dot: Apply a halftone effect.
	Sketch: Apply a pen sketch effect.
	Fish-eye: Blacken the edges of the frame and distort objects to imitate the visual effect of a fisheye lens.
	Defog: Make a photo clearer.
% L	Classic: Apply a black and white effect.

Icon	Description
A R	Retro: Apply a sepia tone effect.
3	Negative: Apply a negative film effect.
₽GB	Custom RGB: Customize a color value.


Available filters in Movie mode

Icon	Description
□	Normal: No effect
İô	Palette Effect 1: Create a vivid look with sharp contrast and red color.
Ìå₂	Palette Effect 2: Make scenes clean and clear by applying a soft blue tone.
ŧδ	Palette Effect 3: Apply a soft brown tone.
İх	Palette Effect 4: Create a cold and monotone effect.
	Miniature: Apply a tilt-shift effect to make the subject appear in miniature.
(Vignetting: Apply the retro-looking colors, high contrast, and strong vignette effect of Lomo cameras.
	Half Tone Dot: Apply a halftone effect.

Icon	Description
#	Sketch: Apply a pen sketch effect.
	Fish-eye: Distort close objects to imitate the visual effect of a fisheye lens.
	Defog: Make the images clearer.
% L	Classic: Apply a black and white effect.
€ R	Retro: Apply a sepia tone effect.
A	Negative: Apply a negative film effect.
[GB]	Custom RGB: Customize a color value.

Defining your own RGB tone

- 1 In Shooting mode, touch → Smart Filter.
- 2 Select Custom RGB, and then touch OK.
- 3 Drag up or down to adjust the values of each color.
 - . The higher the value, the brighter the photo.
 - . The lower the value, the darker the photo.



4 Touch **OK** to save your changes.




- If you select Miniature when you are recording a video, the speed of the video will increase.
- If you select Miniature when you are recording a video, the camera will not record sound.
- If you select Miniature, Vignetting, Half Tone Dot, Sketch, Fish-eye, or Defog while recording a video, the recording speed will be set to \(\frac{\mathbb{H}}{2} \) and the recording resolution will be set to less than 640.
- If you set Smart Filter effects, you cannot use the Face Recognition options, ACB, burst options, Image Adjustment options, Intelli zoom, or Smart Touch AF.
- If you select **Sketch** when you capture a photo, the photo resolution will change to **5m** and below.

Adjusting your photos

Adjust the sharpness, saturation, or contrast of your photos.

- 1 In Shooting mode, touch → Image Adjust.
- 2 Drag up or down to adjust each value.
 - Sharpness
 - O: Contrast
 - III: Saturation



3 Touch **OK** to save your changes.

Sharpness	Description
-	Soften the edges on your photos (suitable for editing the photos on your computer).
+	Sharpen the edges to improve the clarity of your photos. This may also increase the noise on your photos.

Contrast	Description
-	Decrease the color and brightness.
+	Increase the color and brightness.
	Description
-	Decrease the saturation.
	Increase the saturation.



- . Select 0 if you do not want to apply any effects (suitable for printing).
- If you set adjustment functions, you cannot use Smart Filter options.

Reducing the sound of the zoom

When you use the zoom while recording videos, the camera can record the sound of the zoom in the videos. Use the Sound Alive function to reduce the zoom noise.

- 1 In Shooting mode, touch → Voice.
- 2 Select an option, and then touch **OK**.







- Do not block the microphone when you use the Sound Alive function.
- Recordings made with Sound Alive may differ from actual sounds.

Available shooting options by shooting mode

For details about shooting options, refer to "Shooting options".

	Smart Auto	Simple Shot	Dual IS	Scene	Close Up	Night Shot	Beauty Shot	Program	Movie
Resolution	0	0	0	0	0	0	0	0	0
Quality	-	0	0	0	0	0	0	0	0
Timer	Δ	0	0	0	0	0	0	0	Δ
Flash	Δ	Δ	-	Δ	-	Δ	Δ	0	-
ISO sensitivity	-	-	-	-	-	-	-	0	-
Macro	Δ	Δ	-	Δ	Δ	-	Δ	0	0
Focus area	-	-	-	-	-	-	-	0	-
Face detection	Δ	-	-	Δ	-	-	Δ	0	-
EV	-	-	-	-	-	-	-	0	0
ACB	Δ	-	-	Δ	-	-	-	0	-
Metering	-	-	-	-	-	-	-	0	0
White balance	-	-	-	-	-	-	-	0	0
Drive	-	-	-	-	-	-	-	0	-
Smart filter	-	-	-	-	-	-	-	Δ	Δ
Image adjust	-	-	-	-	-	-	-	0	-
Sound Alive	-	-	-	-	-	-	-	-	0
Digital zoom	-	-	-	Δ	-	-	-	0	-
Intelli zoom	Δ	-	-	Δ	-	-	-	Δ	-
OIS	0	0	0	0	0	0	0	0	0
Voice memo	-	-	-	-	-	-	-	0	-

 \triangle In these modes, some options are limited or a certain option is set by default. O The option is available in this mode.

	Smart Movie	Object Highlight	Magic Frame shot	Photo Filter	Movie Filter	Vignetting (photo)	Vignetting (movie)	Palette Effect Shot
Resolution	0	Δ	-	0	0	0	0	0
Quality	0	0	0	0	-	0	0	0
Timer	Δ	0	0	0	Δ	0	Δ	Δ
Flash	-	Δ	0	Δ	-	Δ	-	-
ISO sensitivity	-	-	-	-	-	-	-	-
Macro	Δ	-	-	-	Δ	-	Δ	Δ
Focus area	-	-	-	-	-	-	-	-
Face detection	-	-	-	-	-	-	-	-
EV	-	-	-	-	-	-	-	-
ACB	-	-	-	-	-	-	-	-
Metering	-	-	-	-	-	-	-	-
White balance	-	-	-	-	-	-	-	-
Drive	-	-	-	-	-	-	-	-
Smart filter	-	-	-	Δ	Δ	-	-	Δ
Image adjust	-	-	-	-	-	-	-	-
Sound Alive	0	-	-	-	0	-	0	0
Digital zoom	-	-	-	-	-	-	-	-
Intelli zoom	-	-	-	-	-	-	-	-
OIS	0	0	0	0	0	0	0	0
Voice memo	-	-	-	-	-	-	-	-

 $[\]Delta$ In these modes, some options are limited or a certain option is set by default. O The option is available in this mode.

Playback/Editing

Learn how to play back photos, videos, or voice memos and edit photos or videos.

Also, learn how to connect your camera to your computer, photo printer, TV, or HDTV.

Viewing photos or videos in	Transfer
Playback mode 80	Window
Starting Playback mode 80	Transf
Viewing photos	Transf
Playing a video	the ca
Playing a voice memo	Disco
Editing a photo	(for W
Resizing photos	Transferi
Rotating a photo	Mac cor
Using Smart Crop	Printing
Applying Smart Filter effects	photo pr
Adjusting your photos	
Creating a print order (DPOF)	
Viewing files on a TV or HDTV 97	

Transferring files to your	
Windows computer	. 99
Transferring files with Intelli-studio	100
Transferring files by connecting	
the camera as a removable disk	102
Disconnecting the camera	
(for Windows XP)	103
Transferring files to your	
Mac computer	104
Printing photos with a PictBridge	
photo printer	105


Viewing photos or videos in Playback mode

Learn how to play back photos, videos, or voice memos and how to manage files.

Starting Playback mode

View photos or play videos and voice memos stored in your camera.

1 Press [Playback].



- · The most recent file will be displayed.
- If the camera is off, it will turn on and display the most recent file.



2 Drag the image left or right to move to another file.



- To skip files quickly, tilt the camera in the direction you want to flip files. (p. 81)
- You can also touch and hold the left end or right end of the screen to skip files quickly.
- You can also drag the slider left or right to move to the previous or next file.





- . If you want to view files stored in the internal memory, remove your memory card.
- . The camera will not play back files of unsupported sizes or files that were captured with other cameras properly.

Viewing files with motion recognition

You can view files by tilting the camera in Playback mode.



· Motion recognition may not work well if you hold the camera with the screen parallel to the ground.



- When you rotate the camera 90° or 180° while you view a photo, the camera will automatically change the orientation of the displayed photo. (p. 112)
- To deactivate motion recognition, touch wa, and then touch the setting button next to Gesture View.

Display in Playback mode



Icon	Description
96	Photo includes a voice memo
0	Play videos (p. 89) or voice memos (p. 91)
100-0001	Folder name – File name
00:20	Video length
От	Protected file
	Print order has been set (DPOF)
m	Delete files (p. 86)
r	Play a slide show (p. 88)
8	View files as thumbnails (p. 85)




To display file information on the screen, touch [55], and then touch the setting button next to File Information.

Ranking your favorite faces

You can rank your favorite faces or delete them. The favorite face feature is available only when you insert a memory card into the camera.

1 In Playback mode, touch → Face List.

In Thumbnail view or Smart album, touch → Face List.



2 To change the rank of a face, touch ★23 → Yes, and then drag the face to a new location.



- 3 Touch **OK** to save your changes.
 - To delete a face from the list, touch m, touch the face, and then touch OK.



Viewing files in Smart album as thumbnails

View files by category, such as date, face, or file type.

- 1 On the Home screen, touch .
- 2 Touch **ALL** → a category option.



Icon	Description
ALL	View all files.
=	View files by the date they were saved.
2	View files by recognized faces and favorite faces.
	View files by the file type.



- It may take some time for the camera to open Smart album, change the category, or reorganize files.
- . If you delete a category, all files in the category will be deleted.

Viewing files in 3D view

- 1 On the Home screen, touch .
- 2 Drag images left or right to move to the previous or next file.
 - Flick the screen left or right to switch files more quickly. The faster you flick the screen, the more files you will scroll through at a time.





- · You cannot play movies or voice memos in 3D view.
- The 3D feature is not available while the camera is connected to a TV.

Viewing files with the page flip effect

You can flip through files by dragging or flicking the touch pen across the screen. You can also run a slide show with the flip page effect by touching the slide show icon on the left side.

- 2 Touch a theme (Travel, Wedding, or Party).
- 3 Drag images to the left or right to move to the previous or next file.



Icon	Description
(F)	Play a slide show. Touch the screen to pause the slide show and adjust the volume or mute the sound. Touch to stop the slide show.
5	Return to the theme selection screen.



You can view only photos when you use the page flip effect.

Viewing files as thumbnails

Scan thumbnails of files.




In Playback mode, push [**Zoom**] down to view thumbnails (9 at a time). Push [**Zoom**] down once or twice more to display more thumbnails (16 or 36 at a time).

Push $[{\bf Zoom}]$ up to return to the previous view.



Icon	Description
â	Delete files
•	Photo includes a voice memo
0	Video file
D	Voice memo file



Protecting files

Protect your files to prevent accidental deletion.

- 1 In Playback mode, locate the file you want to protect, and then touch MENU.
- 7 Touch the setting button next to Protect.



You cannot delete or rotate a protected file.

Deleting files

Select files to delete in Playback mode.

Deleting a single file

You can select one file, and then delete it.

- In Playback mode, locate the file you want to delete, and then touch m.
- When the pop-up message appears, touch Yes.



You can also delete a file by touching ■ → Delete → Delete → OK → Yes.

Deleting multiple files

You can select multiple files, and then delete them at once.

- In Thumbnail view, touch in.
- Select the files you want to delete, and then touch in.
- When the pop-up message appears, touch Yes.



When you sort files by category, deleting a category will delete all files in that category.

Deleting all files

You can select all files, and then delete them at once.

- 1 In Playback mode, touch MENU → Delete.
 - In Thumbnail view or Smart album, touch → Delete.
- 2 Select All, and then touch OK.
- 3 When the pop-up message appears, touch Yes.

Copying files to a memory card

Copy files from the internal memory to a memory card.

- - In Thumbnail view or Smart album, touch
 → Copy to Card.
- 2 Touch Copy to Card.
- 3 When the pop-up message appears, touch Yes.

Viewing photos

Enlarge part of a photo or view photos as a slide show.

Enlarging a photo



In Playback mode, push [**Zoom**] up to enlarge a portion of the photo. Push [**Zoom**] down to zoom out.



Drag the screen to see another part of the photo.

Description
Delete the file.
Crop the photo (the camera will save it as a new file).
Return to the original view.
Zoom ratio (The maximum zoom ratio differs depending on the photo resolution.)



When you view photos that were captured by another camera, the zoom ratio may differ.

Playing a slide show

Apply effects and audio to a slide show of your photos. The slide show function does not work for videos or voice memos.

- 1 On the Home screen, touch . A picture appears.
- 2 Touch 록; on the bottom right of the screen. A screen with thumbnails appears.
- 3 Select the photos you want to include in your slide show.
 - Touch an individual photo to select it. Touch it again to deselect it.
 - Touch to select all.
 - Touch 🖫 to cancel your selections.
 - · You cannot select video files.
 - · You can select up to 2,000 files.

4 Touch OK.

5 Touch and then set a slide show effect.



* Default

Icon	Description
ĊŪ	Play Mode: Set whether or not to repeat the slide show. (One Play*, Repeat)
1.	Interval: Set the interval between photos. (1 see*, 3 sec, 5 sec, 10 sec) You must set the Effect option to the interval.
OFF	Music: Set background audio. (Off*, Mist, Drops, Muse, Trip, Fall)
₽	Fifect: Set a scene change effect between photos. (Off*, Calm, Shine, Relax, Lively, Sweet) Select http://doi.org/10.1009/10.

6 Touch to start the slide show.

- · Touch the screen to pause the slide show.
- Touch to stop the slide show.

Playing a video

In Playback mode, you can view a video, and then capture or trim parts of the playing video. You can save the captured or trimmed segments as new files.


- In Playback mode, locate a video, and then touch .
- 2 View the video.



Icon	Description
44	Scan backward.
/ ▶	Pause or resume playback.
>>	Scan forward.
4)	Adjust the volume or mute the sound.
Þ	Return to Playback mode.

Trimming a video

- 1 While viewing a video, touch | | at the point where you want the trimming to begin.
- 2 Touch $\rightarrow \rightarrow \rightarrow$.
- 3 Touch II at the point where you want the trimming to end.
 - You can also adjust the scene to be cropped by dragging the handles that appear on the progress bar.



- 4 Touch %.
- 5 When the pop-up message appears, touch Yes.



- . The original video should be at least 10 seconds long.
- . The camera will save the edited video as a new file.

Capturing an image from video

- 1 While viewing a video, touch II at the point where you want to capture an image.
- 2 Touch 📳.
- 3 When the pop-up message appears, touch Yes.



- The resolution of the captured image will be the same as the original video.
- . The captured image is saved as a new file.

Playing a voice memo

Listening to a voice memo

- 1 In Playback mode, locate a voice memo file, and then touch .
- 2 Listen to the voice memo.



Icon	Description
44	Scan backward.
/ ▶	Pause or resume playback.
>>	Scan forward.
4)	Adjust the volume or mute the sound.
Ð	Return to Playback mode.

Playing voice memos that are attached to photos

- In Playback mode, locate a photo that includes a voice memo, and then touch §.
- 2 Listen to the voice memo.



Icon	Description
/ ▶	Pause or resume playback.
4)	Adjust the volume or mute the sound.
Ð	Return to Playback mode.

Editing a photo

Learn how to edit photos.




- . The camera will save edited photos as new files.
- When you edit photos, the camera will automatically convert them to a lower resolution. Photos that you rotate or resize manually are not automatically converted to a lower resolution. Rotated photos overwrite the original files.

Resizing photos

Change the size of a photo and save it as a new file. You can also select a photo to be displayed when the camera turns on.

- 1 In Playback mode, locate a photo, and then touch
- 2 Touch **Resize**, and then select a size option.
 - Select Start Image to save the photo as a start image. (p. 109)




3 Touch **OK** to save.



Available resize options differ depending on the original size of the photo.

Rotating a photo

- 1 In Playback mode, locate a photo, and then touch
- 2 Touch Rotate, and then select a rotate option.



3 Touch **OK** to save.



Using Smart Crop

Use Smart Crop to select objects in a photo and save the cropped area as a new file.

- 1 In Playback mode, locate a photo, and then touch
- 2 Touch Smart Crop.
- 3 Touch 4 points on the screen to select an area.
 - You can re-select the area by dragging the 4 points.



- 4 Touch **OK** to save.
 - · The cropped photo is saved as a new file.



The size of the new file may be smaller than the original.

Applying Smart Filter effects

Apply special effects to your photos.

- 1 On the Home screen, touch ...
 - The most recent file will be displayed.
- 2 Touch $\mathbb{Z} \to a$ photo.
- 3 Touch MENU → Smart Filter.
- 4 Select a filter.
 - · To see available filter options, refer to page 72.
 - · To view the original photo, touch Before.
 - · To view the photo with the filter effect, touch After.



5 Touch 🖥 to save your changes or touch 🗗 to exit without saving.

Adjusting your photos

Learn how to adjust the brightness, contrast, or saturation and how to correct the red-eye effect. If the center of a photo is dark, you can adjust it to be brighter. The camera will save an edited photo as a new file, but may convert it to a lower resolution.



- You can adjust brightness, contrast, and saturation and apply Smart Filter effects at the same time.
- You cannot apply the ACB, Face Retouch, and Red-eye Fix effects at the same time.

Adjusting brightness, contrast, or saturation

- 1 On the Home screen, touch S.
 - · The most recent file will be displayed.
- 3 Touch → an adjusting option.

Icon	Description
	Brightness
	Contrast
Ш	Saturation

- 4 Drag the sliders or touch the sample photos to adjust the option.
 - · To view the original photo, touch Before.
 - · To view the adjusted photo, touch After.
- 5 Touch to save your changes.

Adjusting dark subjects (ACB)

- 1 On the Home screen, touch N
 - · The most recent file will be displayed.
- 2 Touch $\triangle \rightarrow$ a photo.
- 3 Touch Man → ACB.
 - · To view the original photo, touch Before.
 - · To view the adjusted photo, touch After.
- 4 Touch 🖺 to save your changes.

Retouching faces

- 1 On the Home screen, touch S.
 - · The most recent file will be displayed.
- 2 Touch \square \rightarrow a photo.
- 3 Touch Face Retouch.
- 4 Drag the sliders or touch the sample photos to adjust the skin tone.
 - · As the slider moves to the right, the skin tone becomes brighter.
 - · To view the original photo, touch Before.
 - · To view the adjusted photo, touch After.
- 5 Touch 🖺 to save your changes.

Removing red-eye


- 1 On the Home screen, touch S.
 - · The most recent file will be displayed.
- 2 Touch $\mathbb{Z} \to a$ photo.
- 3 Touch MENU → Red-eye Fix.
 - To view the original photo, touch Before.
 - · To view the adjusted photo, touch After.
- 4 Touch 🖶 to save your changes.

Creating a print order (DPOF)

Select photos to print and save print options in the Digital Print Order Format (DPOF). This information is saved in the MISC folder on your memory card for convenient printing on DPOF-compatible printers.

- 1 In Playback mode, locate a photo, and then touch
- 2 Touch DPOF.

3 Touch +/- to select the number of copies, and then touch 0K.






- You can take the memory card to a print shop that supports DPOF (Digital Print Order Format) or you can print photos directly through a DPOF-compatible printer at home.
- Photos with dimensions that are wider than the paper may be cut off on the left and right edges. Ensure that your photo dimensions are compatible with the paper you select.
- You cannot set DPOF options for photos stored in the internal memory.

Viewing files on a TV or HDTV

Play back photos or videos by connecting your camera to a TV with the AV cable.

- 1 On the Home screen, touch .
- 2 Touch Connectivity → Video Out.
- 3 Select the appropriate video signal output for your country or region. (p. 110)
- 4 Turn off your camera and TV.
- 5 Connect your camera to your TV with the A/V cable.



6 Turn on your TV, and then select a video output mode and the video source (AV 1, etc.) with the TV remote control.

- 7 Turn on your camera.
 - The camera automatically enters into Playback mode when you connect it to a TV.
- 8 View photos or play videos using the touch screen on your camera.



- Depending on the TV model, you may see some digital noise or part of an image may not appear.
- The camera automatically enters Playback mode when you connect it to a TV.

Viewing files on an HDTV

You can view high-quality and uncompressed photos or videos on an HDTV using the optional HDMI cable. HDMI (High Definition Multimedia Interface) is supported by most HDTVs. For details, see the HDMI Kit manual.

- 1 On the Home screen, touch 3.
- 2 Touch Connectivity → HDMI Output.
- 3 Select an HDMI resolution.
- 4 Turn off your camera and HDTV.
- 5 Connect your camera to your HDTV using an optional HDMI cable.



- 6 Turn on your camera and your TV.
 - If you have an Anynet+ compatible Samsung HDTV, the HDTV will turn on automatically and display the camera screen.
 - If you turn Anynet+ off, the HDTV does not turn on automatically.
- 7 If your TV does not have Anynet +, use your TV remote to select the video source (HDMI 1, HDMI2, etc.).
- 8 View files using the touch screen on your camera. If you have Anynet+, you can use your TV's remote.



- If your HDTV supports the Anynet+(CEC) profile, turn Anynet+ on in the camera's settings menu (p.110) to control the camera and TV with the TV's remote control.
- Anynet+ lets you control all connected Samsung AV devices with the TV remote control.
- The time it takes for the camera to connect to your HDTV may vary
 with the type of microSD or microSDHC card you use. A faster
 microSD or microSDHC card will not necessarily result in a faster
 HDMI transfer, because the main function of the card is to improve
 transfer rates during shooting.

Transferring files to your Windows computer

Transfer files to your Windows computer, edit them with Intelli-studio, and upload them to the web.

Requirements

Item	Requirements
CPU	Intel Pentium 4, 3.2 GHz or higher/AMD Athlon™ FX 2.6 GHz or higher
RAM	Minimum 512 MB RAM (1 GB or more recommended)
OS	Windows XP SP2, Windows Vista, or Windows 7 (32-bit editions)
Hard disk capacity	250 MB or more (1 GB and above recommended)
Others	CD-ROM drive 1024 X 768 pixels, 16-bit color display compatible monitor (1280 X 1024 pixels, 32-bit color display recommended) USB 2.0 port NIDIA Geforce 7600GT or higher/ATI X1600 series or higher Microsoft DirectX 9.0c or higher

^{*} The programs may not work properly on 64-bit editions of Windows XP, Windows Vista, and Windows 7



- The requirements are recommendation only. Intelli-studio may not work properly even when the computer meets the requirements, depending on the condition of your computer.
- If your computer does not meet the requirements, videos may not play correctly or it may take longer to edit videos.
- Install DirectX 9.0c or above before you use the program.
- Your computer must be running Windows XP, Windows Vista, or Windows 7 for you to connect the camera as a removable disk. (p. 102 and p. 99)



Samsung is not responsible for any damage that results from using a computer that do not meet the requirements such as a computer you have assembled yourself.

Transferring files with Intelli-studio

Intelli-studio will start automatically when you connect the camera to your computer with the USB cable.



The battery will charge while the camera is connected to a computer with the LISR cable

- 1 On the Home screen, touch .
- 2 Touch Connectivity, and then turn on PC Software by touching the setting button.
- 3 Turn off the camera.
- 4 Connect the camera to your computer with the USB cable.



You must plug the end of the cable with the indicator light (\(\big)\) into your camera. If the cable is reversed, it may damage your files. The manufacturer is not responsible for any loss of data.



- 5 Turn on the camera.
 - The computer recognizes the camera automatically and Intellistudio launches automatically.



If you set the USB option to **Select Mode**, select **Computer** in the pop-up window.

- 6 Select a destination folder on your computer, and then select Yes
 - New files stored on the camera will automatically transfer to the selected folder.
 - If your camera has no new files, the pop-up window for saving new files will not appear.



For Windows Vista and Windows 7, select **Run iStudio.exe** from the Auto Play window to start Intelli-studio.

Using Intelli-studio

Intelli-studio is a built-in program that allows you to play back and edit files. For details, select **Help** \rightarrow **Help** on the program toolbar.



- To enjoy more features, such as creating slide shows with templates, install the full version of Intelli-studio by selecting Web Support → Update Intelli-studio → Start Update from the program toolbar.
- You can update the firmware of your camera by selecting Web Support → Upgrade firmware for the connected device from the program toolbar.
- If you install Intelli-studio on your computer, the program will launch more quickly. To install the program, select Tool → Install Intelli-studio on PC.
- · You cannot edit files directly on the camera. Transfer files to a folder on your computer before editing.
- · Intelli-studio supports the following formats:
 - Videos: MP4 (Video: H.264, Audio: AAC), WMV (WMV 7/8/9), AVI (MJPEG)
 - Photos: JPG, GIF, BMP, PNG, TIFF



Playback/Editing 101

	Description
0	Open menus.
2	Display files in the selected folder.
3	Switch to the Photo edit mode.
4	Switch to the Video edit mode.
6	Switch to the Sharing mode. (to send files by email or upload files to websites, such as Flickr or YouTube)
6	Enlarge or reduce the thumbnails in the list.
7	Select a file type.
8	View files in the selected folder on your computer.
9	Show or hide files on the connected camera.
10	View files in the selected folder on the camera.
0	View files as thumbnails or on a map.
D	Browse folders stored on the camera.
B	Browse folders stored on your computer.
14	Move to the previous or next folder.
13	Print files, view files on a map, store files in My Folder, or register faces.

Transferring files by connecting the camera as a removable disk

Connect the camera to your Windows computer as a removable disk.

- 1 On the Home screen, touch .
- 2 Touch Connectivity, and then turn off PC Software by touching the setting button.
- 3 Turn off the camera.
- 4 Connect the camera to your computer with the USB cable.



You must plug the end of the cable with the indicator light (\(\bigai)\) into your camera. If the cable is reversed, it may damage your files. The manufacturer is not responsible for any loss of data.



- 5 Turn on the camera.
 - · The computer recognizes the camera automatically.



If you set the USB option to **Select Mode**, select **Computer** in the pop-up window.

- 6 On your computer, select My Computer → Removable Disk → DCIM → 100PHOTO.
- 7 Drag or save files to your computer.

Disconnecting the camera (for Windows XP)

For Windows Vista and Windows 7, the methods for disconnecting the camera are similar.

- 1 If the status lamp on your camera is blinking, wait until it stops.
- 2 Click on the tool bar at the bottom right of your computer screen.



- 3 Click the pop-up message.
- 4 Click the message box indicating safely removed.
- 5 Remove the USB cable.



The camera may not disconnect safely while Intelli-studio is running. End the program before disconnecting the camera.

Transferring files to your Mac computer

When you connect the camera to a Macintosh computer, the computer will automatically recognize the device. You can transfer files directly from the camera to the computer without installing any programs.




Mac OS 10.4 or later is supported.

1 Connect your camera to a Macintosh computer with the USB cable.



You must plug the end of the cable with the indicator light (A) into your camera. If the cable is reversed, it may damage your files. The manufacturer is not responsible for any loss of data.



- 7 Turn on the camera.
 - . The computer recognizes the camera automatically and displays a removable disk icon.



If you set the USB option to Select Mode, select Computer in the pop-up window.

- Double-click the removable disk icon.
- Drag or save files to your computer.

Printing photos with a PictBridge photo printer


Print photos with a PictBridge compatible printer by connecting your camera directly to the printer.

- 1 On the Home screen, touch .
- 2 Touch Connectivity → USB → Printer.
- 3 Turn on the printer, and then connect your camera to the printer with the USB cable.



- 4 If the camera is off, press [POWER] or [Playback] to turn it on.
 - · The printer recognizes the camera automatically.
- 5 Select a file to print.
- 6 Touch +/- to select the number of copies.
 - To set printer options, touch . (p. 106)


- 7 Touch ## to print.
 - Touch at to print all photos.



- 8 When the pop-up window appears, touch Yes to begin printing.
 - To cancel printing, touch Cancel on the pop-up window.

Configuring print settings

Press www to configure print settings.







Settings Refer to options to configure your camera's settings.

Settings menu	108
Accessing the settings menu	108
Sound	109
Display	109
Connectivity	110
Conorol	

Settings menu

Learn to configure your camera's settings.

Accessing the settings menu

- 1 On the Home screen, touch .
- 2 Touch a menu.






3 Touch an item.



4 Select an option, and then touch **OK**.



5 Touch to return to the previous screen.

Sound

	* Default
Item	Description
Volume	Set the volume of any sound. (Off, Low, Medium*, High)
Beep Sound	Set to emit sounds when you touch the screen or switch modes. (Off, On*)
Shutter Sound	Set the sound the camera emits when you press the shutter button. (Off, 1*, 2, 3)
Start Sound	Set the sound the camera emits when you turn on your camera. (Off*, 1, 2, 3)
AF Sound	Set to emit a sound when you half-press the shutter button. (Off, On*)

Display

	* Default
	Description
Start Image	Set a start image to display when the camera turns on. Off: Display no start image. Logo: Display a default image stored in the internal memory. User Image: Display a custom image. (p. 92) The camera will save only one User Start Image in the internal memory at a time. If you select a new photo as a User Start Image or reset your camera, the camera will delete the current image.
Guide Line	Set a grid to help you compose a scene. (2 X 2*, 3 X 3, X, +)

	* Default
Item	Description
Display Brightness	Adjust the brightness of the screen. (Auto, Dark, Normal, Bright*) Normal is fixed in Playback mode even if you have selected Auto.
Quick View	Set the duration for reviewing a captured image before returning to the Shooting mode. (Off, 0.5 seo*, 1 sec, 3 sec)
Power Save	If you perform no operations for 30 seconds, the camera automatically switches to Power save mode. (Off*, On) • In Power save mode, press any button other than [POWER] to resume using the camera. • Even if you do not set the Power save mode, the screen will dim 30 seconds after the last operation to save power.

Connectivity

	* Defaul	
Item		
Video Out	Set the video signal output for your region. NTSC*: USA, Canada, Japan, Korea, Taiwan, Mexico PAL (supports only BDGHI): Australia, Austria, Belgium, China, Denmark, England, Finland, Germany, Italy, Kuwait, Malaysia, Netherlands, New Zealand, Norway, Singapore, Spain, Sweden. Switzerland. Thailland	
Anynet+ (HDMI-CEC)	Set whether or not to control the camera with a 1 remote control when you connect it to an HDTV that supports the Anynet+(CEC) profile. • Off: View files without using an HDTV remote control. • On*: Control the camera with an HDTV remote control.	

	* Default	
	Description	
HDMI Output	Set the resolution of photos when the camera plays back files on an HDTV via the HDMI cable. (NTSC: 1080i*, 720p, 480p/ PAL: 1080i*, 720p, 576p) • If the HDTV does not support the selected resolution, the HDTV automatically selects the next lower resolution. • If you select 480p or 576p, the playback menus and Smart Album will not be available when you connect the camera to a TV.	
USB	Select the mode to use when you connect the camera to a computer or printer with a USB cable. Computer*: Connect your camera to a computer to transfer files. Printer: Connect your camera to a printer to print files. Select Mode: Manually select the USB mode when you connect your camera to a device.	
PC Software	Set Intelli-studio to launch automatically when you connect your camera to your computer. (Off, On*)	

General

	* Default	
Item	Description	
Language	Set a language for the display text.	
Time Zone	Set the time zone for your location. When you travel to another country, touch Visit , and then touch the appropriate time zone.	
Date/Time Set	Set the date and time.	
Date Type	Set a date format. (YYYY/MM/DD, MM/DD/YYYY, DD/MM/YYYY, Off*)	

	* Default	
	Description	
	Specify how to name files. Reset: Set the file number to start from 0001 when you insert a new memory card, format a memory card, or delete all files. Series*: Set the file number to resume from the previous file number when you insert a new memory card, format a memory card, or delete all files.	
File No.	The default name of the first folder is 100PHOTO and the default name of the first file is SAM_0001. The file number increases one at a time from SAM_0001 to SAM_999. The folder number increases one at a time from 100PHOTO to 999PHOTO. The maximum number of files that can be stored in one folder is 9,999. The camera defines file names according to the Design rule for Camera File system (DCF) standard. If you intentionally change file names, the camera may not play back the files.	

	* Default	
Item	Description	
Auto Rotate	Set to automatically rotate photos as you rotate the camera. (Off, On*)	
Imprint	Set to display the date and time on captured photos. (Off*, Date, Date & Time) • The date and time will be displayed on the bottom right comer of the photo. • Some printer models may not print the date and	
	time properly. If you select Text in Scene mode, the camera will not display the date and time.	
	Set the camera to automatically turn off when you perform no operations for a specified period. (Off, 1 min, 3 min*, 5 min, 10 min)	
Auto Power Off	Your settings will not change when you replace the battery. The camera will not automatically turn off when the camera is connected to a computer or printer, when you are playing a slide show or videos, and when you are recording a voice memo.	

	0	foi	

Item	Description	
AF Lamp	Set a light to automatically turn on in dark places to help the camera focus. (Off, On*)	
	Format the internal memory and the memory card Formatting will delete all files, including protected files. (Yes, No)	
Format	Errors can occur if you use a memory card formatted by another brand of camera, a memory card reader, or a computer. Please format memory cards in the camera before using them to capture photos.	
Reset	Reset menus and shooting options except date and time, language, and video output settings. (Yes, No)	
Touch Calibration	Calibrate the touch screen so that your camera will properly recognize your inputs.	

Appendixes

Get information about error messages, specifications, and maintenance.

Error messages11
Camera maintenance
Cleaning your camera11
Using or storing the camera11
About memory cards
About the battery
Before contacting a service center
Camera specifications
Glossary
FCC notice
Index

Error messages

When the following error messages appear, try these remedies.


Error message	Suggested remedies	
Card Error	 Turn off your camera, and then turn it on again. Remove your memory card, and then insert it again. Format your memory card. 	
Card not supported.	The inserted memory card is not supported by your camera. Insert a microSD or microSDHC memory card.	
DCF Full Error	File names do not match the DCF standard. Transfer the files on the memory card to your computer, and then format the card.	
File Error	Delete the damaged file or contact a service center.	
File system not supported.	Your camera does not support the FAT file structure of the inserted memory card. Format the memory card on the camera.	
Low Battery	Insert a charged battery or recharge the battery.	
Memory Full	Delete unnecessary files or insert a new memory card.	
No Image File	Capture photos or insert a memory card that contains some photos.	

Camera maintenance

Cleaning your camera


Camera lens and touch screen

Use a blower brush to remove dust and wipe the lens gently with a soft cloth. If any dust remains, apply lens cleaning liquid to a piece of lens cleaning paper and wipe gently.



Camera body

Wipe gently with a soft, dry cloth.





- Never use benzene, thinners, or alcohol to clean the camera. These solutions can damage the camera or cause it to malfunction.
- Do not press on the lens cover or use a blower brush on the lens cover.

Using or storing the camera

Inappropriate places to use or store the camera

- Avoid exposing the camera to very cold or very hot temperatures.
- Avoid using your camera in areas with extremely high humidity, or where the humidity changes drastically.
- Avoid exposing the camera to direct sunlight and storing it in hot, poorly-ventilated areas, such as in a car during summertime.
- Protect your camera and the display from impact, rough handling, and excessive vibration to avoid serious damage.
- Avoid using or storing your camera in dusty, dirty, humid, or poorly-ventilated areas to prevent damage to moving parts and internal components.
- Do not use your camera near fuels, combustibles, or flammable chemicals. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the camera or its accessories.
- . Do not store the camera where there are mothballs.

Using on beaches or shores

- Protect your camera from sand and dirt when you use it on beaches or in other similar areas.
- Your camera is not waterproof. Do not handle the battery, adapter, or memory card with wet hands. Operating the camera with wet hands may cause damage to your camera.

Storing for extended period of time

- When you store the camera for an extended period, place it in a sealed container with an absorbent material, such as silica gel.
- Remove the batteries from your camera when storing it for an extended period. Installed batteries may leak or corrode over time and cause serious damage to your camera.
- Over time, unused batteries will discharge and must be recharged before use.

Using the camera with caution in humid environments

When you transfer the camera from a cold environment to a warm one, condensation can form on the lens or internal components of the camera. In this situation, turn off the camera and wait for at least 1 hour. If condensation forms on the memory card, remove the memory card from the camera and wait until all moisture has evaporated before reinserting it.

Other cautions

- Do not swing your camera by the strap. This may cause injury to yourself or others or damage to your camera.
- Do not paint your camera, as paint can clog moving parts and prevent proper operation.
- . Turn off the camera while not in use.
- Your camera consists of delicate parts. Avoid impacts to the camera.
- Protect the display from external force by keeping it in the case when not in use. Protect the camera from scratches by keeping it away from sand, sharp implements, or loose change.
- Do not expose the lens to direct sunlight, as this may discolor the image sensor or cause it to malfunction.
- Protect your lens from fingerprints and scratches. Clean your lens with a soft, clean, debris-free lens cloth.
- The camera may turn off if subjected to a sudden impact. This
 is to protect the memory card. Turn on the camera to use it
 again.
- While you use the camera, it may heat up. This is normal and should not affect your camera's lifespan or performance.
- When you use the camera in low temperatures, it may take some time to turn on, the screen color may be changed temporarily, or after-images may appear. These conditions are not malfunctions and they will correct themselves when the camera is returned to normal temperatures.

- Paint or metal on the outside of the camera may cause allergies, itchy skin, eczema, or swelling for people with sensitive skin. If you experience any of these symptoms, stop using the camera immediately and consult a doctor.
- Do not insert foreign objects into any of your camera's compartments, slots, or access points. Damage due to improper use may not be covered by your warranty.
- Do not allow unqualified personnel to service the camera or attempt to service the camera yourself. Any damage that results from unqualified service is not covered by your warranty.

About memory cards

Supported memory cards

Your camera supports microSD (Secure Digital) or microSDHC (Secure Digital High Capacity) memory cards.



To read data with a PC or memory card reader, insert the memory card into a memory card adapter.

Memory card capacity

The memory capacity may vary depending on the scenes you shoot and the shooting conditions. The capacities below are based on a a 1 GB microSD card:

	Size	Super Fine	Fine	Normal	30 FPS	15 FPS
Р	16m	105	206	303	-	-
	Pin	117	230	337	-	-
	20	140	275	406	-	-
h o	IOm	166	323	469	-	-
t	5 m	319	607	858	-	-
S	3m	522	954	1,336	-	-
	<u>2m</u>	742	1,336	1,878	-	-
	lm	1,582	2,505	3,006	-	-
*	1280 HQ	-	-	-	Approx. 13' 08"	Approx. 22' 57"
V d e o s	1280	-	-	-	Approx. 14' 55"	Approx. 25' 54"
	640	-	-	-	Approx. 34' 55"	Approx. 65' 40"
	320	-	-	-	Approx. 134' 34"	Approx. 231' 14"

^{*} Available recording time may vary if you use the zoom. Several videos were recorded in succession to determine the total recording time.

Cautions when using memory cards

- Insert a memory card in the correct direction. Inserting a memory card in the wrong direction may damage your camera and memory card.
- Do not use memory cards that have been formatted by other cameras or by a computer. Reformat the memory card with your camera.
- Turn off the camera when you insert or remove the memory card.
- Do not remove the memory card or turn off your camera while the lamp is blinking, as this may damage your data.
- When the lifespan of a memory card has expired, you cannot store any more photos on the card. Use a new memory card.
- Do not bend, drop, or subject memory cards to heavy impact or pressure.
- Avoid using or storing memory cards near strong magnetic fields.
- Avoid using or keeping memory cards in areas with high temperature, high humidity, or corrosive substances.
- Prevent memory cards from making contact with liquids, dirt, or foreign substances. If dirty, wipe the memory card clean with a soft cloth before you insert the memory card in your camera.
- Do not allow liquids, dirt, or foreign substances to come in contact with memory cards or the memory card slot. Doing so may cause memory cards or the camera to malfunction.

- When you carry a memory card, use a case to protect the card from electrostatic discharges.
- Transfer important data to other media, such as a hard disk, CD, or DVD.
- When you use the camera for an extended period, the memory card may become warm. This is normal and does not indicate a malfunction.



The manufacturer is not responsible for any loss of data.

About the battery

Use only Samsung-approved batteries.

Battery specifications

Specification	Description	
Model	BP70A	
Туре	Lithium-ion battery	
Cell capacity	740 mAh (min. 700 mAh)	
Voltage	3.7 V	
Charging time* (when the camera is switched off)	Approximately 150 min	

^{*} Charging the battery by connecting it to a computer may take longer.

Battery life

Average shooting time / Number of photos		Test conditions and procedures (when the battery is fully charged)	
		Camera settings: in Program mode, in the darkness, at resolution, with OIS off, Fine quality.	
	Approximately 95 min/ Approximately 190 photos	Procedure:	
Photos		Set the flash option to Fill in , take a single shot, and zoom in or out.	
		Set the flash option to Off , take a single shot, and zoom in or out.	
		Perform steps 1 and 2 for 30 seconds and repeat for 5 minutes. Then turn off the camera for 1 minute.	
		4. Repeat steps 1 to 3.	
Videos	Approximately 70 min	Record videos at 1280 X 720 HQ resolution and 30 FPS.	

- The figures above are measured using Samsung's standards. Your reslutts may vary, depending on your actual usage
- Several videos were recorded in succession to determine the total recording time.

Low battery message

When the battery has fully discharged, the battery icon will turn red and the "Low Battery" message will appear.

Notes about using the battery

- Avoid exposing batteries or memory cards to very cold or very hot temperatures (below 0 °C/32 °F or above 40 °C/104 °F).
 Extreme temperatures can reduce the charging capacity of your batteries and can cause memory cards to malfunction.
- When you use the camera for an extended period, the area around the battery chamber may become warm. This does not affect the normal use of the camera.
- Do not pull the power supply cord to disconnect the plug from the power outlet, as this may cause a fire or electric shock.
- In temperatures below 0 °C/32 °F, battery capacity and battery life may decrease.
- Battery capacity may decrease in low temperatures but will return to normal in milder temperatures.

Cautions about using the battery

Protect batteries, chargers, and memory cards from damage

Prevent batteries from making contact with metal objects. Contact can create a connection between the + and – terminals of your battery and lead to temporary or permanent battery damage and may cause a fire or electric shock.

Notes about charging the battery

- If the indicator light is off, make sure that the battery is inserted correctly.
- If the camera is on while the battery is charging, the battery may not fully charge. Turn off the camera before charging the battery.
- Do not use your camera when you are charging the battery. This may cause a fire or electric shock.
- Do not pull the power supply cord to disconnect the plug from the power outlet. This may cause a fire or electric shock.
- Let the battery charge for at least 10 minutes before turning on the camera again.
- If you connect the camera to an external power source when the battery is depleted, using some high energy-consuming functions will cause the camera to turn off. To use the camera normally, recharge the battery.

Camera maintenance

- Using the flash or recording videos depletes the battery quickly.
 Charge the battery until the indicator light turns green.
- If the indicator light blinks in orange or does not illuminate, reconnect the cable, or remove the battery and insert it again.
- If you charge the battery when the cable is overheated or the temperature is too high, the indicator light may turn orange.
 Charging will start when the battery cools down.
- Overcharging batteries may shorten battery life. After charging is finished, disconnect the cable from your camera.
- Do not bend or place heavy objects on the AC cable. Doing so may damage the cable.

Notes about charging with a computer connected

- Use only the provided USB cable.
- · The battery may not charge when:
 - you use a USB hub
 - other USB devices are connected to your computer
 - you connect the cable to the port on the front side of your computer
 - the USB port of your computer does not support the power output standard (5 V, 500 mA)

Handling and disposing of batteries and chargers with care

- Never dispose of batteries in a fire. Follow all local regulations when you dispose of used batteries.
- Never place batteries or cameras on or in heating devices, such as microwave ovens, stoves, or radiators. Batteries may explode when they are overheated.



Personal injury or death can occur if the battery is handled carelessly or improperly. For your safety,

follow these instructions for proper battery handling:

- The battery can ignite or explode if not handled properly. If you notice any deformities, cracks, or other abnormalities in the battery, immediately discontinue use of the battery and contact a service center.
- Use only authentic, manufacturer-recommend battery chargers and adapters and charge the battery only by the methods described in this user manual.
- Do not place the battery near heating devices or expose it to excessively warm environments, such as the inside of an enclosed car in the summertime.
- · Do not place the battery in a microwave oven.
- Avoid storing or using the battery in hot, humid places, such as spas or shower enclosures.
- Do not rest the device on flammable surfaces, such as bedding, carpets, or electric blankets for a prolonged period.
- When the device is switched on, do not leave it in any confined space for a prolonged period.
- Do not allow battery terminals to come in contact with metallic objects, such as necklaces, coins, keys, or watches.
- Use only authentic, manufacturer-recommended, Lithiumion replacement batteries.

- Do not disassemble the battery or puncture it with any sharp object.
- Avoid exposing the battery to high pressure or crushing forces.
- Avoid exposing the battery to major impacts, such as dropping it from high places.
- Do not expose the battery to temperatures of 60 °C (140 °F) or above.
- Do not allow the battery to come in contact with moisture or liquids.
- Do not expose the battery to sources of excessive heat such as direct sunshine, fire or the like.

Disposal guidelines

- · Dispose of the battery with care.
- · Do not dispose of the battery in a fire.
- Disposal regulations may differ by country or region.
 Dispose of the battery in accordance with all local and federal regulations.

Guidelines for charging the battery

Charge the battery only by the method described in this user manual. The battery can ignite or explode if not charged properly.

Before contacting a service center

If you are having trouble with your camera, try these troubleshooting procedures before you contact a service center. If you have attempted the suggested remedy and are still having problems with your device, contact your local dealer or service center.



When you leave your camera at a service center, be sure to also leave the other components that may have contributed to the malfunction, such as the memory card and battery.

Situation	Suggested remedies
Cannot turn on the camera	 Ensure that the battery is inserted. Ensure that the battery is inserted correctly. (p. 16) Charge the battery.
The power turns off suddenly	Charge the battery. Your camera may be in Power save mode. (p. 112) The camera may turn off to prevent the memory card from being damaged due to an impact. Turn on your camera again.
The camera is losing battery power quickly	The battery may lose power more quickly in low temperatures (below 0 °C/32 °F). Keep the battery warm by putting it into your pocket. Using the flash or recording videos depletes the battery quickly. Recharge if needed. Batteries are consumable parts that must be replaced over time. Get a new battery if the battery life is diminishing quickly.

	Suggested remedies	
Cannot capture photos	There is no space on the memory card. Delete unnecessary files or insert a new card. Format the memory card. The memory card is defective. Get a new memory card. Make sure that the camera is switched on. Charge the battery. Make sure that the battery is inserted correctly.	
The camera freezes	Remove the battery and insert it again.	
The camera heats up	While you use the camera, it may heat up. This is normal and should not affect your camera's lifespan or performance.	
The flash does not work	The flash option may be set to off. (p. 55)You cannot use the flash in some modes.	

Situation		
The flash fires unexpectedly	The flash may fire due to static electricity. The camera is not malfunctioning.	
The date and time are incorrect	Set the date and time in the display settings. (p. 111)	
The touch screen or buttons do not work	Remove the battery and insert it again.	
The camera screen responds poorly	If you use your camera at very low temperatures, it may cause the camera screen to malfunction or discolor. For better performance of your camera screen, use your camera in moderate temperatures.	
The memory card has an error	Turn off your camera and then turn it on again. Remove your memory card and insert it again. Format your memory card. See "Cautions when using memory cards" for more detail. (p. 119)	
Cannot play back files	If you change the name of a file, your camera may not play the file (the name of the file should meet the DCF standard). If you encounter this situation, play back the files on your computer.	

Situation	Suggested remedies	
The photo is blurry	 Make sure that the focus option you set is suitable for close-up shots. (p. 58) Make sure that the lens is clean. If not, clean the lens. (p. 116) Make sure that the subject is within range of the flash. (p. 127) 	
The colors in the photo do not match the actual scene	An incorrect White Balance can create unrealistic color. Select the proper White Balance option to suit the light source. (p. 69)	
The photo is too bright	Your photo is overexposed. Turn off the flash. (p. 55) Adjust the ISO sensitivity. (p. 57) Adjust the exposure value. (p. 67)	
The photo is too dark	Your photo is underexposed. Turn on the flash. (p. 55) Adjust the ISO sensitivity. (p. 57) Adjust the exposure value. (p. 67)	

Situation	Suggested remedies	
The TV does not display your photos	 Make sure that the camera is correctly connected to the TV with the AV cable. Make sure that your memory card contains photos. 	
Your computer does not recognize your camera	 Make sure that the USB cable is connected correctly. Make sure that your camera is switched on. Make sure that you are using a supported operating system. 	
Your computer disconnects the camera while transferring files	The file transmission may be interrupted by static electricity. Disconnect the USB cable and connect it again.	
Your computer cannot play videos	Videos may not play on some video player programs. To play video files captured with your camera, install and use the Intelli-studio program on your computer. (p. 100)	

Situation	Suggested remedies	
Intelli-studio is not functioning properly	End Intelli-studio and restart the program. You cannot use Intelli-studio on Macintosh computers. Make sure that PC Software is turned on in the settings menu. (p. 111) Depending on your computer's specifications and environment, the program may not launch automatically. If this occurs, click Start → My Computer → Intelli-studio → iStudio.exe on your computer.	

Camera specifications

Image sensor				
Туре	1/2.3" (Approximately 7.76 mm) CCD			
Effective pixels	Approximately 16.2 mega-pixels			
Total pixels	Approximately 16.4 mega-pixels			
Lens				
Focal length	Samsung Lens f = 4.7 mm-23.5 mm (35 mm film equivalent: 26 mm-130 mm)			
F-stop range	F3.3 (W)-F5.9 (T)			
Digital zoom	Still image mode: 1.0X-5.0X (Optical zoom x Digital zoom: 25.0X) Playback mode: 1.0X-14.4X			
Display				
Туре	TFT LCD			
Feature	3.0" (7.6 cm) Wide 230 K Full Touch Screen Panel			

Focusing			
Туре	TTL auto focus (Multi AF, Center AF, Smart Face Recognition AF, Face Detection AF, Smart Touch AF, One Touch Shooting AF)		
		Wide (W)	Tele (T)
D	Normal (AF)	80 cm-infinity	1.5 m-infinity
Range	Macro	5 cm-80 cm	1 m-1.5 m
	Auto Macro	5 cm-infinity	1 m-infinity

Shutter speed

- Smart Auto: 1/8-1/2,000 sec.
- Program: 1-1/2,000 sec.
- Night Shot: 8-1/2,000 sec.

Exposure		
Control	Program AE	
Metering	Multi, Spot, Center-weighted, Face Detection	
Compensation	±2EV (1/3 EV Step)	
ISO equivalent	Auto, ISO 80, ISO 100, ISO 200, ISO 400, ISO 800, ISO 1600, ISO 3200	

Camera specifications

Flash		White Balance	•
Mode Auto, Red-eye, Fill in, Slow Sync, Off, Red-eye Fix		Auto WB, Daylight, Cloudy, Fluorescent_H, Fluorescent_L, Tungsten,	
Wodo	Wide: 0.2 m-3.0 m (ISO Auto)	Custom Set	
Range	Tele: 1.0 m-1.8 m (ISO Auto)	Date Imprinting	
Recharging time	Approximately 4 sec.	Date & Time, Date, Off	
Shake reduction		Shooting	
DUAL IS [Optical Image Stabilization (OIS) + Digital Image Stabilization (DIS)] Effect			Modes: Smart Auto*, Program, Scene*, Simple Shot, Magic Frame shot, Beauty Shot, Object Highlight, Night Shot, Close Up, Vignetting, Photo
Photo Shooting mode	Photo Filter (Smart Filter): (Normal), Miniature, Vignetting, Soft Focus, Old Film 1, Old Film 2, Half Tone Dot, Sketch, Fish-eye, Defog, Classic, Retro, Negative, (Custom RGB) Image Adjust: Sharpness, Contrast, Saturation	Photos Action, Tripod, Night, N Backlight Portrait, Blue	
Video Shooting mode	Palette Effect Shot: Palette Effect 1, Palette Effect 2, Palette Effect 3, Palette Effect 4 Movie Filter (Smart Filter): (Normal), Miniature, Vignetting, Half Tone Dot, Sketch, Fish-eye, Defog, Classic, Retro, Negative, (Custom RGB)	 * Scene: Landscape, Text, Sunset, Dawn, Backlig & Snow • Drive: Single, Continuous, Motion Capture • Timer: 2 Sec, 10 Sec, Double 	

Videos	Modes: Movie, Smart Movie*, Vignetting, Movie Filter, Palette Effect Shot *Smart Movie: Landscape, Blue Sky, Natural Green, Sunset Format: MP4 (H.264) (Maximum recording time: 20 min) Size: 1280 X 720 HQ, 1280 X 720, 640 X 480, 320 X 240 Frame rate: 30 FPS, 15 FPS Voice: Mute, Sound Alive On, Sound Alive Off OIS: On, Off Video editing (embedded): Pause during recording, Still image capture, Time trimming
Playback	
Туре	Single image, Thumbnails, Multi-slide show with music and effect, Movie clip, Smart Album*, 3D Album, Magazine View * Smart Album category: Type, Date, Face
Edit	Resize, Rotate, Image Adjust, Trim, Smart Crop, Smart Filter
Effect	Image Adjust: Face Retouch, Brightness, Saturation, Contrast, Red-eye Fix, ACB Smart Filter: Normal, Miniature, Vignetting, Soft Focus, Old Film 1, Old Film 2, Half Tone Dot, Sketch, Fish-eye, Defog, Classic, Retro, Negative, Custom RGB

Voice recording

- Voice Recording (Maximum 10 hours)
- Voice Memo in a photo (Maximum 10 sec.)

Storage	
Media	Internal memory: Approximately 10 MB External memory (Optional): microSD card (up to 2 GB guaranteed), microSDHC card (up to 8 GB guaranteed) Internal memory capacity may not match these specifications.
File format	DCF, EXIF 2.21, DPOF 1.1, PictBridge 1.0 Still Image: JPEG (DCF) Movie Clip: MP4 (Video: MPEG-4.AVC/H.264, Audio: AAC) Audio file: WAV

Camera specifications

For 1 GB microSD: Number of photos Super Fine Fine Normal 16m 4608 X 3456 105 206 303 4608 X 3072 117 230 337 4608 X 2592 140 275 406 10m 3648 X 2736 166 323 469	
16m 4608 X 3456 105 206 303 ← 4608 X 3072 117 230 337 ← 4608 X 2592 140 275 406	
4608 X 3072 117 230 337 4608 X 2592 140 275 406	
4608 X 2592 140 275 406	
IDm 3648 X 2736 166 323 469	
55 15 17 27 36 160 525 466	
mage size 5m 2592 X 1944 319 607 858	
3m 1984 X 1488 522 954 1,336	
1920 X 1080 742 1,336 1,878	
Im 1024 X 768 1,582 2,505 3,006	

These figures are measured under Samsung's standard conditions. Your results may vary depending on the shooting conditions and camera settings.

Interface				
Digital output connector	USB 2.0			
Audio input/output	Internal speaker (Mono), Microphone (Mono)			
Video output	AV: NTSC, PAL (selectable) HDMI 1.4: NTSC, PAL (selectable)			
DC power input connector	20 pin, 4.2 V			

Power source	Power source	
Rechargeable battery	Lithium-ion battery (BP70A, 740 mAh: Min 700 mAh)	

The power source may differ depending on your region.

Dimensions (W X H X D)

102.3 X 56.5 X 19.3 mm (without protrusions)

Weight

126.5 g / 4.46 oz (without battery and memory card)

Operating Temperature

0-40 °C / 32-104° F

Operating Humidity

5-85 %

Software

Intelli-studio

Specifications may change without notice to improve performance.

Glossary

ACB (Auto Contrast Balance)

This feature automatically improves the contrast of your images when the subject is backlit or when there is a high contrast between your subject and the background.

AEB (Auto Exposure Bracket)

This feature automatically captures several images at different exposures to help you capture a properly-exposed image.

AF (Auto Focus)

A system that automatically focuses the camera lens on the subject. Your camera uses the contrast to focus automatically.

Aperture

The aperture controls the amount of light that reaches the camera's sensor.

Camera shake (Blur)

If the camera is moved while the shutter is open, the entire image may appear blurred. This occurs more often when the shutter speed is slow. Prevent camera shake by raising the sensitivity, using the flash, or using a faster shutter speed. Alternately, use a tripod, the DIS or OIS function to stabilize the camera.

Composition

Composition in photography means arranging objects in a photo. Usually, abiding by the rule of thirds leads to a good composition.

DCF (Design rule for Camera File system)

A specification to define a file format and file system for digital cameras created by the Japan Electronics and Information Technology Industries Association (JEITA).

Depth of field

The distance between the nearest and farthest points that can be acceptably focused in a photograph. Depth of field varies with lens aperture, focal length, and distance from the camera to the subject. Selecting a smaller aperture, for example, will increase the depth of field and blur the background of a composition.

Digital zoom

A feature that artificially increases the amount of zoom available with a zoom lens (Optical zoom). When using the Digital zoom, the image quality will deteriorate as the magnification increases.

DPOF (Digital Print Order Format)

A format for writing printing information, such as selected images and number of prints, on a memory card. DPOF-compatible printers, sometimes available at photo shops, can read the information from the card for convenient printing.

EV (Exposure Value)

All the combinations of the camera's shutter speed and lens aperture that result in the same exposure.

EV Compensation

This feature allows you to quickly adjust the exposure value measured by the camera, in limited increments, to improve the exposure of your photos. Set the EV compensation to -1.0 EV to adjust the value one step darker and 1.0 EV to one step brighter.

Exif (Exchangeable Image File Format)

A specification to define an image file format for digital cameras created by the Japan Electronic Industries Development Association (JEIDA).

Exposure

The amount of light allowed to reach the camera's sensor. Exposure is controlled by a combination of the shutter speed, the aperture value, and ISO sensitivity.

Flash

A speed light that helps to create adequate exposure in low-light conditions.

Focal length

The distance from the middle of the lens to its focal point (in millimeters). Longer focal lengths result in narrower angles of view and the subject is magnified. Shorter focal lengths result in wider angles of view.

Histogram

A graphical representation of the brightness of an image. The horizontal axis represents the brightness and the vertical axis represents the number of pixels. High points at the left (too dark) and right (too bright) on the histogram indicate a photo that is improperly exposed.

H.264/MPEG-4

A high-compression video format established by international standard organizations ISO-IEC and ITU-T. This codec is capable of providing good video quality at low bit rates developed by the Joint Video Team (JVT).

Image sensor

The physical part of a digital camera that contains a photosite for each pixel in the image. Each photosite records the brightness of the light that strikes it during an exposure. Common sensor types are CCD (Charge-coupled Device) and CMOS (Complementary Metal Oxide Semiconductor).

ISO sensitivity

The sensitivity of the camera to light, based on the equivalent film speed used in a film camera. At higher ISO sensitivity settings, the camera uses a higher shutter speed, which can reduce blur caused by camera shake and low light. However, images with high sensitivity are more susceptible to noise.

JPEG (Joint Photographic Experts Group)

A lossy method of compression for digital images. JPEG images are compressed to reduce their overall file size with minimal deterioration of the image resolution.

LCD (Liquid Crystal Display)

A visual display commonly used in consumer electronics. This display needs a separate backlight, such as CCFL or LED, to reproduce colors.

Macro

This feature allows you to capture close-up photos of very small objects. When using the macro feature, the camera can maintain a sharp focus on small objects at a near life-size ratio (1:1).

Metering

The metering refers to the way in which the camera measures the quantity of light to set the exposure.

MJPEG (Motion JPEG)

A video format which is compressed as a JPEG image.

Noise

Misinterpreted pixels in a digital image that may appear as misplaced or random, bright pixels. Noise usually occurs when photos are shot with a high sensitivity or when a sensitivity is automatically set in a dark place.

Optical zoom

This is a general zoom which can enlarge images with a lens and does not deteriorate quality of images.

Quality

An expression of the rate of compression used in a digital image. Higher quality images have a lower rate of compression, which usually results in a larger file size.

Resolution

The number of pixels present in a digital image. High resolution images contain more pixels and typically show more detail than low resolution images.

Shutter speed

Shutter speed refers to the amount of time it takes to open and close the shutter, and it is an important factor in the brightness of a photo, as it controls the amount of light which passes through the aperture before it reaches the image sensor. A fast shutter speed allows less time to let light in and the photo becomes darker and more easily freezes subjects in motion.

Vignetting

A reduction of an image's brightness or saturation at the periphery (outer edges) compared to the center of the image. Vignetting can draw interest to subjects positioned in the center of an image.

White balance (color balance)

An adjustment of the intensities of colors (typically the primary colors red, green, and blue), in an image. The goal of adjusting the white balance, or color balance, is to correctly render the colors in an image.



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.



PlanetFirst represents Samsung Electronics' commitment to sustainable development and social responsibility through eco-driven business and management activities.



Correct disposal of batteries in this product

(Applicable in the European Union and other European countries with separate battery return systems)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.

This Class [B] digital apparatus complies with Canadian ICES-003.

Dispose unwanted electronics through an approved recycler. To find the nearest recycling location, go to our website: www.samsung.com/recyclingdirect Or call, (877) 278 - 0799

FCC notice

· NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorientate, or relocate, the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

· CAUTION:

Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

· Declaration of Conformity

Trade Name : Samsung Electronics America, Inc.

Model No. : Samsung ST6500

Responsible Party : Samsung Electronics America, Inc.

Address : 85 Challenger Road, Ridgefield Park,

NJ 07660

Telephone No. : 1-800-SAMSUNG (726-7864)

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2)

this device must accept any interference received, including

interference that may cause undesired operation.

Index

Α

AF-assist light

location 14 settings 113

AF Lamp 113

AF Sound 109

Anynet+ 110

Aperture value 37

Auto Contrast Balance (ACB)

Playback mode 95 Shooting mode 67

Auto Exposure Bracket (AEB) 71

A/V port 14

В

Battery

caution 121 charging 17 inserting 16

Beauty Shot mode 37

Blink detection 64

Brightness

Playback mode 94 Shooting mode 67

Burst modes

Auto Exposure Bracket 71 Continuous 71 Motion Capture 71 C

Camera maintenance 116

Camera specifications 127

Charging 17

Cleaning

camera body 116 lens 116 touch screen 116

Close up shot

Close up mode 36 macro 58

Connecting to a computer

Mac 104 Windows 99

Contrast

Playback mode 94 Shooting mode 75 D

Date/Time set 111

Deleting files 86

DIgital Print Order Format (DPOF) 96

Digital zoom 27

Disconnecting the camera 103

Display brightness 110

Display set 23

DUAL IS mode 35

Е

Editing photos 92

Editing videos

capturing 90 trimming 90

Enlarging 87

Error messages 115

F н Image quality 52 Motion capture 71 Motion recognition 81 Imprint 112 Face detection 62 Half-press shutter 30 Intelli-studio 101 Movie Filter mode 45 Flash HDMI Output 111 Auto 55 Intelli zoom 28 My star HDTV 98 Fill in 56 ranking 82 ISO sensitivity 57 Off 55 Home button 15 registering 65 Red-eve 56 Home screen 24 Red-eye fix 56 Ν Slow sync 56 Language settings 111 Focus area Night Shot mode 37 Center AF 61 Learning icons 20 Icons Multi AF 61 Home screen 24 0 One touch shooting 61 Playback mode 82 M Smart Touch AF 61 Shooting mode 20 Object Highlight mode 42 Macro 58 Focus sound 109 One touch shooting 60 Image adjustment brightness Magic Frame Shot mode 43 Formatting 113 Optical Image Stabilization Playback mode 94 (OIS) 29 Memory card Shooting mode 67 caution 119 contrast G Optional accessories 13 Playback mode 94 Insert 16 Shooting mode 75 Guide lines 109 Metering red-eve 96 Center-weighted 69 saturation Playback mode 94 Multi 69

Spot 69

Shooting mode 75

sharpness 75

P

Palette Effect mode 47

Photo Filter mode 43

PictBridge 105

Playback button 15

Playback mode 80

Power button 14

Power save mode 110

Printing photos 105

Program mode 38

Protecting files 86

Q

Quick view 110

R

Red-eye

Playback mode 96 Shooting mode 55

Reset 113

Resolution

Playback mode 92 Shooting mode 51

Retouching faces

Playback mode 95 Shooting mode 37

Rotating 93

S

Saturation

Playback mode 94 Shooting mode 75

Scene mode 36

Self portrait shot 63

Service center 124

Settings 108

Sharpness 75

Shooting portraits

Beauty Shot mode 37 Blink detection 64 Face detection 62

Red-eye 56

Red-eye fix 56 Self portrait 63

Smart Face Recognition 64

Smile shot 63

Shutter button 14

Simple Shot mode 34

Slide show 88

Smart Album 83

Smart Auto mode 33

Smart Crop 93

Smart Face Recognition 64

Smart Filter

Playback mode 94 Shooting mode 72

Smart Movie mode 40

Smile shot 63

Sound settings 23

Start image 92, 109

Status lamp 15

Т

Thumbnails 83

Timer

timer lamp 14 Using the timer 54

Time settings 18, 111

Time zone settings 18, 111

Touch calibration 19, 113

Touch screen 15

Transferring files

Mac 104 Windows 99

Tripod mount 14

U

Unpacking 13

USB port 14

User buttons 38

Using the touch screen

flicking 21 scrolling 21 touching 21

V

Video

playing 89 shooting 39

Viewing files

page flip effect 84 slide show 88 Smart Album 83 thumbnails 85 TV 97

Vignetting mode 46

Voice memo

playing 91 recording 48

W

White Balance 69

Z

Zoom

using the zoom 27 zoom button 15 zoom sound settings 76



Please refer to the warranty that came with your product or visit our website http://www.samsung.com/ for after-sales service or inquiries.

